



Data-Voice-Video 3G Power Solutions

Installation and Operation Guide

Issue: IPN 997-00012-54D

Issue Date: November 2012

**Refer to the separate SC200 or SC100 system controller handbook for full
details of the system controller operation -
dcpower.eaton.com/Manuals.asp**

Eaton Corporation
Telecommunications Power Solutions
dcpower.eaton.com
DCinfo@eaton.com

The product discussed in this literature is subject to terms and conditions outlined in Eaton selling policies. The sole source governing the rights and remedies of any purchaser of this equipment is the relevant Eaton selling policy.

No warranties, express or implied, including warranties of fitness for a particular purpose or merchantability, or warranties arising from course of dealing or usage of trade, are made regarding the information, recommendations and descriptions contained herein.

In no event will Eaton be responsible to the purchaser or user in contract, in tort (including negligence), strict liability or otherwise for any special, indirect, incidental or consequential damage or loss whatsoever, including but not limited to damage or loss of use of equipment, plant or power system, cost of capital, loss of power, additional expenses in the use of existing power facilities, or claims against the purchaser or user by its customers resulting from the use of the information, recommendations and descriptions contained herein.

The information contained in this literature is subject to change without notice.

Subject to the right to use its equipment, Eaton Corporation does not convey any right, title or interest in its intellectual property, including, without limitation, its patents, copyrights and know-how.

No part of this literature may be reproduced or transmitted in any form, by any means or for any purpose other than the Purchaser's personal use, without the express written permission of Eaton Corporation.

Eaton®, Matrix, Powerware®, Intergy™, CellSure™, SiteSure™, PowerManagerII™ and DCTools™ are trade names, trademarks, and/or service marks of Eaton Corporation or its subsidiaries and affiliates. Unless otherwise noted, brands, product names, trademarks or registered trademarks are the property of their respective holders.

Copyright © 2005-2012 Eaton Corporation. All Rights Reserved.

Purpose

This guide provides instructions to correctly install, commission and operate Eaton Data-Voice-Video 3G Power Solutions (DV2-3G).

Audience

This guide is intended for use by:

- Installers competent in:
 - installing and commissioning dc power systems
 - safe working practices for ac and dc powered equipment
 - the relevant local electrical safety regulations and wiring standards
- Operators and maintenance staff competent in:
 - operation of dc power systems
 - safe working practices for ac and dc powered equipment

Scope

This guide covers installation, commissioning, operation and maintenance of Eaton Data-Voice-Video 3G Power Solutions.

It does not cover:

- System controller operations; installation of external alarm and user digital inputs cabling; or setup of communications options or software. For details refer to the system controller operation handbook listed under Related Information.
- Installation and configuration of Eaton SiteSure and CellSure modules. For details, refer to the relevant guide listed under Related Information.

Related Information

- PowerManagerII Online Help
- DCTools Online Help
- SC100 System Controller Operation Handbook – IPN 997-00012-63*
- SC200 System Controller Operation Handbook – IPN 997-00012-50*
- SiteSure-3G Installation and Operation Guide – IPN 997-00012-51
- CellSure Installation Guide – IPN 997-00012-20

* Download from: <http://dcpower.eaton.com/Manuals.asp>.

Reporting Problems with this Guide

Please use this email address to report any problems you find in this guide:

Eaton DC Product Marketing Communications

EMAIL: DCMarketingNZ@eaton.com

For Further Information and Technical Assistance

For further information and technical assistance see Worldwide Support on page [103](#).

About This Guide

Purpose	i
Audience.....	i
Scope	i
Related Information	i
Reporting Problems with this Guide	ii
For Further Information and Technical Assistance	ii

Chapter 1**General Description**

Overview	1
Typical DV2-3G DC Power Systems.....	2
Rectifiers	3
System Controller	4
SC200 System Controller	4
SC100 System Controller	5
Compatible Software.....	5
Input/Output Board	6
Connections.....	7
Other Features	8
External communications.....	8
Low Voltage Disconnect (LVD) option.....	8
External current shunts/sensors option.....	8
Battery Mid-point Monitoring Description (SC200 only).....	9
Battery Time Remaining.....	9

Chapter 2**Preparation**

Overview	11
Warnings	12
Inspecting the Equipment and Reporting Damage	14

Chapter 3**Installation**

Overview	15
Installation Tasks.....	16
DC Installation Practices.....	16
Order of Tasks.....	17
Task 1 - Check the AC Supply and Earthing	17
Task 2 - Fixing the Power System Cabinet(s)	20
Task 3 - Connect the Output to Earth.....	22
Task 4 - Connect the DC Load Cables	24
Task 5 - Connect Battery Cables (if required).....	25
Task 6 - Install the Batteries	27
Task 7 - Mount the Battery Temperature Sensor	30
Task 8 - Connect External Current Sensors/Shunts (if required)	31
Task 9 - Connect Input/Output Cabling (if required)	31
Task 10 - Connect Additional Input/Output (if required)	32
Task 11 - Connect Battery Fuse Fail (if required)	32
Task 12 - Connect to the AC Supply	33
Installation Completed	36

Chapter 4	Start-Up	
Overview	37	
Start-Up Tasks	38	
Task 1 - Inserting the Rectifiers	38	
Task 2 - Pre-Power-Up Checklist	39	
Task 3 - Applying AC Power.....	39	
Task 4 - Configuring the DC Power System.....	40	
Task 5 - Apply DC Power to Battery and Load	41	
Start-Up Completed.....	42	
Chapter 5	System Controller	
Configuration File	44	
Backup and Restore	44	
Starting the SC200 or SC100	45	
SC200	45	
SC100	45	
SC200 or SC100 Operation using the Keypad and Screen.....	46	
Keypad Access Security	46	
Alarm Indicators	47	
SC200 or SC100 Operation Using a PC/Laptop	48	
Using DCTools via USB (SC200 only)	48	
Using DCTools via RS232	48	
SC200 or SC100 Identity Information.....	50	
Chapter 6	Maintenance	
Overview	51	
Troubleshooting	52	
Replacing or Adding a Rectifier.....	56	
Replacing or Adding a Load MCB	57	
Replacing a Load or Battery Fuse Link	58	
Adding a Load Fuse.....	59	
Replacing the System Controller.....	59	
Replacing the Input/Output Board.....	61	
Monitoring and Replacing Transient Protective Devices	63	
Battery Mid-point Monitoring (String Fail) Alarm (SC200 only)	63	
Battery Disposal and Recycling.....	64	


Appendix A	Equipment and Tools	
	Safety Equipment	65
	Essential Tools.....	65
	Recommended Tools.....	65
	Spare Parts.....	66
	Standard Torque Settings.....	67
Appendix B	Specifications	
Appendix C	Cable Ratings	
Appendix D	Controller Menus	
	SC200 Menu	77
	SC100 Menu	78
Appendix E	Connector Pin-outs	
	System Controller Connector Pin-outs.....	79
	I/O Board (IOBGP-00, -01) Connector Pin-outs.....	80
Appendix F	System Components	
	External Current Sensors.....	83
	CS04-A11 current sensor	83
Appendix G	Transient Protection	
Appendix H	Commissioning	
	Analog Inputs	90
	System Controls.....	92
	System Alarms	95
	Digital Inputs	98
	Digital Outputs (Relays).....	99
	Commissioning Completed	99
Equipment Incident Report		
Worldwide Support		
Index		

General Description

Overview

Topic	Page
Typical DV2-3G DC Power Systems	<u>2</u>
Rectifiers	<u>3</u>
System Controller	<u>4</u>
Input/Output Board	<u>6</u>
Other Features	<u>8</u>

Typical DV2-3G DC Power Systems



**Typical system
(rectifiers only)**

- 1 DC distribution section.
- 2 Input/Output (I/O) board (on back of door). See details on page [6](#).
- 3 SC200 or SC100 system controller. See details on page [4](#). (For more details refer to the relevant system controller handbook listed under Related Information.)
- 4 AC distribution with isolator switch and surge protection (located behind door in most models).
- 5 Rectifier magazine(s)* for up to 10 rectifiers per magazine. See details of rectifiers on page [3](#).

**Typical system with
integrated batteries**

- 6 Combined ac and dc distribution section.
- 7 Battery shelves with battery MCBs. (A battery shelf front cover is also supplied, but is not shown.)
- 8 Optional plinth for use with raised floors (Eaton part number: PLINIR-A00). See details on page [20](#).
- 9 An optional security door (not shown) is also available.

Battery rack (option)




These diagrams show typical layouts of 43U high racks. Actual system configuration may vary from that shown.

Rectifiers

Data-Voice-Video 3G Power Solutions are fitted with either 48V, 2000W (APR48-ES); 48V, 1800W (APR48-3G); or 24V, 1440W (APR24-3G) rectifiers. The rectifiers are fan-cooled and hot-pluggable.

 See Specifications on page [69](#) for further information. See Troubleshooting on page [52](#) for details of rectifier alarms.



Left: APR24-3G and APR48-3G

Right: APR48-ES

- ① Power On LED (Green)
- ② Minor Alarm LED (Yellow)
- ③ Major Alarm LED (Red)
- ④ Serial Number
- ⑤ Retaining Screw. Tighten to 1.5Nm (13.3 inch-pounds).

System Controller

The SC200 or SC100 system controller provides control, communications and alarm functions.

The system controller is supplied pre-configured. Configuration changes can be made with the keypad, or via a PC connected to the USB connector (SC200) or RS232 (SC100) connector. Or changes can be made remotely (see External Communications on page [8](#)).


For basic operating information see System Controller on page [43](#). For further details refer to the System Controller Operation Handbook (see Related Information).

See Troubleshooting on page [52](#) for details of system controller alarms.

SC200 System Controller


The SC200 system controller is an advanced control and monitoring solution which provides a full suite of communications options, including built-in Ethernet interface, Web server, and SNMP agent.

Alarm notifications may be by Email, SNMP traps, SMS text messaging, dial-out to PowerManagerII remote monitoring software, or relay contact closures.



SC100 System Controller

The SC100 system controller is a full-featured control and monitoring solution which provides alarm notifications via dial-out modem to PowerManagerII remote monitoring software, SMS text messaging, or by relay contact closures.



Compatible Software

The following software is compatible with the SC200 or SC100 system controller:

- DCTools Configuration Software. Latest version is available free from dcpower.eaton.com/downloads.
- PowerManagerII Remote Control and Monitoring Software. Contact your Eaton dc product supplier for further information (see Worldwide Support on page [103](#)).
- Recommended web browsers (SC200 only): Microsoft Internet Explorer 8 or later (IE6 is compatible but with reduced performance), Mozilla Firefox 3.0 or later.

Input/Output Board

The input/output (I/O) board provides the I/O interfaces and connections for the SC200 or SC100 system controller.


The I/O board includes a range of sense inputs for dc power system control and monitoring. It also allows real time data collection from building services and other external devices, and relay outputs for alarm signals or control of external devices.

The I/O functions are:

Sensors: Current - 3, Bus voltage - 1, Temperature - 2, Battery Mid-point - 4
(SC200 only)

Input/Output: Digital inputs: 4 pre-defined system functions, 6 user-defined
Relay outputs: 6 (one also used as Monitor OK alarm)
LVD contactor outputs: 2


 For input and output specifications see details on page [73](#). For connector pin-outs see details on page [80](#).



 See Troubleshooting on page [52](#) for details of I/O board LED signals.

Connections

The following diagram shows the connections between the SC200 or SC100, the I/O board, the other dc power system components and external devices.



① SC200 or SC100 system controller	⑫ Communications to rectifiers
② I/O board	⑬ DC power system digital inputs (Load Fuse Fail, Battery Fuse Fail, AC Distribution Fan Fail, AC Distribution MOV Fail)
③ Voltage feed module	⑭ Connections to battery mid-points (4) (SC200 only)
④ USB communications (SC200 only)	⑮ Connection to temperature sensors (2)
⑤ Ethernet communications (SC200 only)	⑯ Connection to current sensors (3)
⑥ RS232 communications	⑰ Optional LVD contactor and auxiliary switch (see details on page 8)
⑦ Digital relay outputs (6) to external devices and/or alarm indication system	⑱ Optional LVD contactor and auxiliary switch (see details on page 8)
⑧ Digital inputs (6) from external voltage-free switches or relay contacts	⑲ Bus voltage sense and LVD power connections
⑨ Connection to additional I/O board(s) and/or SiteSure-3G I/O module(s) via RJ45 splitter (see details on page 32) (SC200 only)	⑳ I/O and system controller power and RXP comms connections
⑩ Connection to dc common bus	
⑪ Connection to dc live bus	

For connector pin-outs see details on page 80. For input and output specifications see details on page 69.

Other Features

External communications

Refer to the system controller handbook for information on these communications options.

Communications options	SC200	SC100
Communication with <i>DCTools</i> via USB	✓	-
Communication with <i>DCTools</i> or <i>PowerManagerII</i> via RS232	✓	✓
Communication with <i>DCTools</i> or <i>PowerManagerII</i> via an external PSTN or GSM modem (dial-in and dial-out on alarm)	✓	✓
Communication with <i>DCTools</i> or <i>PowerManagerII</i> via Ethernet	✓	-
Communication with web browser software via an IP network	✓	-
Communication with a Network Management System (NMS) using SNMP	✓	-
Communication with a Building Management System (BMS) using Modbus	✓	-
Alarm and status messages to GSM Short Messaging Service (SMS) text capable cell phones	✓	✓
Communication with an alarm management system using voltage-free relay contacts (on an IOBGP I/O board)	✓	✓

Low Voltage Disconnect (LVD) option

Data-Voice-Video 3G Power Solutions may be fitted with one or more Low Voltage Disconnects (LVDs). The way LVDs can be connected is determined by the type of dc power system:

- In dc power systems without integrated batteries the LVD(s) can be connected either as load or battery disconnect(s).
- In dc power systems with integrated batteries the LVD(s) can only be connected as a battery disconnect.

LVDs have two purposes:

- to protect a VRLA battery from deep discharge and premature failure, and/or
- to reduce the load on a battery under discharge so that high priority equipment operates for a longer time after an ac supply failure.

Refer to the SC200 or SC100 system controller handbook for information on how to configure the LVD channels.

External current shunts/sensors option

Various models of external current shunts/sensors are available for use with the Data-Voice-Video 3G Power Solutions to measure battery and/or load currents. The Eaton CS04-A11 current sensor is also available to measure currents in larger systems. See details on page 83.

External current shunts/sensors are connected to the I/O board or to a SiteSure-3G module.

Battery Mid-point Monitoring Description (SC200 only)

Battery Mid-point Monitoring provides a cost-effective method for the early detection of internal battery faults. The voltages of the two halves of a battery string are measured and the system controller generates an alarm signal if a voltage imbalance is detected.

A voltage imbalance is an indication that one or more cells has an internal fault. Further investigation can then isolate the faulty cell(s) and action can be taken to correct the problem and prevent a total battery failure.

To connect Battery Mid-point Monitoring see details on page [27](#). If a *String Fail* alarm is generated see Troubleshooting on page [52](#).

To ensure reliable operation Mid-point Monitoring operates only when the battery is in float charge and after a configurable lockout period since the last battery discharge, Fast Charge, Equalize or Battery Test.

Battery Time Remaining

The SC200 or SC100 obtains characterization data from either periodic battery discharges (SC100) or every full battery discharge (SC200), to a specified end voltage.

During a battery discharge, the SC200 or SC100 uses this characterization data to calculate an estimated time until the battery will reach the specified end voltage.

- *If a battery disconnect LVD is fitted then the end voltage will usually be the voltage at which the LVD disconnects the battery.*
- *Battery Time Remaining is designed for a constant power load. The accuracy of the time remaining calculation will be reduced if the dc power system is connected to a predominantly resistive (constant current) load.*
- *The time remaining calculation will not be correct if a non-essential load is disconnected during the battery discharge.*

For details refer to *Battery Time Remaining* in the SC200 or SC100 System Controller Operation Handbook (see Related Information).



Powering Business Worldwide

Chapter 2

Preparation

Overview

<u>Topic</u>	<u>Page</u>
Warnings	<u>12</u>
Inspecting the Equipment and Reporting Damage	<u>14</u>

Warnings

This section contains important warnings. Read these warnings before installing or operating Data-Voice-Video 3G Power Solutions dc power systems.



Electrical Safety

- The dc earth/ground link must be rated to carry the combined fault current of battery strings. See details on page [22](#).
- If the dc power system is to be installed in a location where the ambient temperature may rise above 45°C (113°F), then 105°C rated cable must be used for all connections.
- The dc power system is not compatible with IT (Impedance Terra) ac supply. For advice see Worldwide Support on page [103](#).
- A registered electrician (or suitably qualified person) must check the integrity of the installed cabling, BEFORE the dc power system is powered up.
- Commissioning must be performed in the sequence documented in this guide.



Location and Environment

- For ease of access and to maintain optimum system cooling observe the clearances stated on page [20](#).
- Dust build-up within the dc power system may cause premature failure. In dusty environments filter the ventilation air entering the equipment room. Ensure regular cleaning of the air filters.
- Do not allow water or any foreign object to enter the dc power system. Do not place objects containing liquid on top of or near the unit.
- Flooded cell and VRLA lead acid batteries can emit explosive gases and must be installed with adequate ventilation. Refer to the battery manufacturer or supplier for advice on minimum ventilation levels.



Reverse Polarity

- Always check that the battery cables have been terminated to the correct system polarity BEFORE connecting the batteries or closing the battery disconnect device. Connecting batteries to the dc power system with incorrect system polarity will damage the rectifiers and void all warranty claims.



Hazardous Energy Levels

- Rectifiers and batteries contain hazardous energy levels. Only personnel trained and experienced in dc power systems are to service/maintain this equipment.
- Always use insulated tools.
- Do not short-circuit the live and common bus bars or cables.



Batteries

- The plastic cases of batteries installed in Eaton dc power system racks must have a flammability rating of UL 94-V2 or better.
- Flooded cell and VRLA lead acid batteries can emit explosive gases and must be installed with adequate ventilation. Refer to the battery manufacturer or supplier for advice on minimum ventilation levels.
- Do not wear a synthetic dust-coat or overalls. Synthetic fabrics can hold static electric charges that create sparks during discharge.
- Remove rings, wristwatch and other metal jewelry that might be exposed to battery terminals, before installing batteries.
- Batteries are powerful sources of energy and present a potential electrical shock and energy hazard. The energy hazard is always present, even if the batteries are not connected. Avoid short circuiting terminals of opposite polarity.
- Always use insulated tools.
- Do not place tools, loose cables or metal objects (such as interconnecting bars) on top of batteries.
- Do not drop tools, loose cables or metal objects onto intercell connections or terminals of opposite polarity.
- Only terminate cables and interconnecting bars after confirming that the termination will not create a short circuit.
- Always tighten battery terminal bolts according to the battery manufacturer's specification. Failing to do so can cause erratic battery performance, possible damage to the battery, and/or personal injury.
- There is a risk of electric shock or explosion if a battery is replaced by an incorrect type.
- Dispose of batteries according to the instructions on page [64](#).



Rectifiers

- Only operate the rectifiers when the surrounding area is clean and dust free.
- To reduce the risk of electric shock and maintain optimum system cooling, always cover empty rectifier slots with blanking panels.
- To avoid electrical shock, do not place hands inside the rectifier magazine.
- Rectifier cases may exceed 100°C (212°F), especially after prolonged operation. Use suitable gloves when removing a rectifier from the magazine.
- Do not attempt to disassemble faulty rectifiers. Return them (in their original packaging) with a completed Equipment Incident Report on page [101](#).
- Ensure that any upstream Residual Current Devices (RCDs) are appropriately rated for the rectifiers' maximum earth leakage current (see Specifications on page [69](#) for value).



DC Distribution(s)

- The dc common bus of the dc power system can be connected to earth (ground). If this connection is made all of the following conditions must be met:
 - Your equipment and the dc power system must be located within the same premises.
 - No switching or disconnecting devices are allowed in the conductor between the dc common line and the point of connection to the earth electrode conductor.
 - Follow all applicable local and national rules and regulations when making field connections.
 - Tighten all electrical connections to the torques stated in this guide or on the manufacturer's label.



Servicing and Maintenance

- The DV2-3G contains hazardous voltages and hazardous energy levels. Before undertaking any maintenance task refer to the Warnings on page [12](#).
- If a maintenance task must be performed on a "live" system then take all necessary precautions to avoid short-circuits or disconnection of the load equipment, and follow any "live-working" instructions applicable to the site.
- Only perform the maintenance tasks described in the Maintenance chapter. All other tasks are classified as Servicing. Servicing must only be performed according to specific instructions and only by personnel authorized by Eaton. This includes disassembly and/or servicing of any modules.
- For further information on Servicing contact your local Eaton dc product supplier, or refer to the contact details on page [103](#).



EMC Compliance

- This dc power system may be used in close proximity to other electronic equipment, provided installation is carried out according to instructions in this guide. However, proper installation and compliance with EMC standards does not guarantee that the dc power system will not respond to electromagnetic disturbances, or will not cause interference to other equipment in a particular installation.
- In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
- This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

Inspecting the Equipment and Reporting Damage

Unpack the equipment and inspect it carefully for possible damage that may have occurred while in transit. Do not use any damaged equipment.

Report any damage immediately, using a completed Equipment Incident Report on page [101](#).

Keep the original packaging to use if any item needs to be returned for replacement or repair.

Overview

Topic	Page
Installation Tasks	<u>16</u>
Task 1 - Check the AC Supply and Earthing	<u>17</u>
Task 2 - Fixing the Power System Cabinet(s)	<u>20</u>
Task 3 - Connect the Output to Earth	<u>22</u>
Task 4 - Connect the DC Load Cables	<u>24</u>
Task 5 - Connect Battery Cables (if required)	<u>25</u>
Task 6 - Install the Batteries	<u>27</u>
Task 7 - Mount the Battery Temperature Sensor	<u>30</u>
Task 8 - Connect External Current Sensors/Shunts (if required)	<u>31</u>
Task 9 - Connect Input/Output Cabling (if required)	<u>31</u>
Task 10 - Connect Additional Input/Output (if required)	<u>32</u>
Task 11 - Connect Battery Fuse Fail (if required)	<u>32</u>
Task 12 - Connect to the AC Supply	<u>33</u>
Installation Completed	<u>36</u>

Installation Tasks

Before starting the installation, review the following information:

- Required Equipment and Tools on page [65](#)
- Warnings and Cautions on page [12](#)
- Inspecting the Equipment and Reporting Damage on page [14](#)

DC Installation Practices

Read the following dc Installation Practices before connecting the dc load and battery cables:

- To avoid excessive voltage drop and overheating, ensure that the dc load and battery cables are appropriately sized to handle the maximum dc output current. Also refer to the table of minimum cable sizes for specific MCBs or fuses on page [75](#). We recommend multi-strand cable with insulation rating of 600-1000V.
- Run the dc load and battery cables through cable glands where they pass through metal parts or covers. Also ensure that each cable gland provides firm strain relief and adequate anchorage for the cable.
- Secure and support all dc load and battery cabling (especially at their connection points) to prevent excessive strain on these cables.
- To reduce inductive coupling, separate dc load, battery and control cabling from ac supply cables. If the cables have to cross, run them at right angles to the ac supply cables.
- In order to minimize parasitic cable inductance and reduce electromagnetic interference (EMI), route all dc load cables in close proximity to one another, and avoid large current loops. The same applies to battery cables.
- Ensure that MCBs/fuses in the dc distribution(s) are clearly labeled.
- Only perform electrical insulation and continuity tests, once all dc load and battery cabling are in place and dc common bus has been earthed.

Order of Tasks

Complete the installation tasks in the following order:

Task	Description	Reference
1	Check the AC Supply and Earthing	See details on page 17
2	Fixing the Power System Cabinet(s)	See details on page 20
3	Connect the Output to Earth	See details on page 22
4	Connect the dc Load Cables	See details on page 24
5	Connect Battery Cables (if required)	See details on page 25
6	Install the Batteries	See details on page 27
7	Mount the Battery Temperature Sensor	See details on page 30
8	Connect External Current Sensors/Shunts (if required)	See details on page 31
9	Connect Input/Output Cabling (if required)	See details on page 31
10	Connect Additional Input/Output (if required)	See details on page 32
11	Connect Battery Fuse Fail (if required)	See details on page 32
12	Connect to AC Supply	See details on page 33

For installation of external communications refer to Communications Options in the system controller Operation Handbook (see Related Information).

Task 1 - Check the AC Supply and Earthing

It is important that the ac supply for the Data-Voice-Video 3G Power Solutions dc power system includes the correct levels of protection.

Step 1 - Check transient voltage protection at the site




- 1 Confirm that there is a transient protection plan (compliant with IEC 61643-12) for the site.
 - ☐ For more information see Transient Protection on page [85](#).
- 2 If necessary, install suitable transient protection.

Step 2 - Check high ac voltage protection at the site



- 1 Check if the ac voltage is expected to exceed 275V (L-N).
- 2 If so, then it is strongly recommended that an external high voltage protection unit (HVPU) be installed. This will automatically disconnect the ac at high voltage and reconnect it at normal voltage.
- 3 Install the HVPU as in the following diagram.
- 4 Connect the High VAC alarm output to one of the Digital Inputs on the I/O board (see the diagram on page [6](#) for location).
 - The High VAC alarm signal lines must be isolated from the ac supply by a voltage-free relay contact.*



<ol style="list-style-type: none"> 1 AC supply 2 Primary transient protection devices 3 High voltage protection unit with alarm output 4 DV2-3G dc power system 	<ol style="list-style-type: none"> 5 Secondary transient protection devices (MOVs) 6 I/O board 7 SC200 or SC100 system controller 8 Rectifiers
---	--

Step 3 - Check the type of ac supply, disconnect device and RCDs



- 1 Check the type of ac supply. Only the types of ac supply listed in the Specifications on page [69](#) are suitable for the DV2-3G.
 - Only use a delta (L-L) ac supply if referenced to earth, or a protection system is in place so that the phase-earth voltage cannot exceed the rating of the rectifier.*
- 2 Check that the DV2-3G will be connected to a suitable upstream ac disconnect device(s).
- 3 Check the disconnect device will isolate both the phase and neutral conductors in single-phase and three-phase connections, unless the neutral conductor is clearly identified.
- 4 Check that any Residual Current Devices (RCD) upstream of the DV2-3G are rated for the maximum earth leakage current of the rectifiers. If necessary, install higher rated RCD(s).
 - The maximum earth leakage current of the rectifiers is given in the Specifications on page [69](#).*

Step 4 - Check ac discrimination




Each rectifier has internal fast-acting fuses. Under certain internal fault conditions these fuses will blow.

If there is insufficient discrimination between these fuses and any upstream ac supply-disconnect device then the upstream ac supply-disconnect device will operate before a rectifier fuse blows. This will disconnect the ac supply to all rectifiers.

- 1 Check the time-current (tripping) curve(s) of all ac supply-disconnect device(s) upstream of the DV2-3G with the following curve for the rectifier fuses.

 Refer to the manufacturer's data for tripping curves.



Time-Current Curve (minimum and maximum) for internal rectifier fuses (IEC 60127-2).

Source: Schurter SP 5x20 Pigtail data sheet.

- 2 No action is required if the time-current curves of the upstream ac supply-disconnect devices are entirely to the right of the curves for the rectifier fuses.
- 3 If the curve of an upstream ac supply-disconnect device crosses the curve for the rectifier fuse there may not be adequate discrimination. If necessary, replace the upstream ac supply-disconnect device to achieve adequate discrimination. Or, contact your Eaton dc product supplier for advice (see Worldwide Support on page [103](#)).

Step 5 - Check the earthing arrangements at the site



Confirm that all earths are brought together at one "star" point so that surge currents cannot flow in "earth loops" and create large voltages.

 For more information see *Transient Protection* on page [85](#).

Procedure complete

Task 2 - Fixing the Power System Cabinet(s)



- The dc power system must be installed in a location classified as 'Restricted Access'. A key or tool is required to gain access to the power system. A sign must also be displayed, warning that the power system metalwork may be hot.
- The dc power system must meet the fire and electrical enclosure requirements specified in AS/NZS 60950.1, EN 60950-1, IEC 60950-1 and UL 60950-1. To maintain compliance with these requirements, all covers must be fitted (including the bottom cover plate, if bottom cable access is not required.)
- Lifting equipment and at least two people are required to safely move the power system. Without lifting equipment four people are required to move the power system safely.

Data-Voice-Video 3G Power Solutions racks are supplied completely assembled. Rectifiers and batteries are always shipped separately.

Step 1 - Check route and clearances



- 1 Check the route of the power system to its final position. Check for:
 - clearances at doorways and other points
 - that the floor can support the weight of the rack and lifting equipment
 - that protective floor coverings are available (if required).
- 2 Check there will be the following minimum clearances around the power system in its final position:
 - Front Clearance – 600mm (24") from walls and other equipment required for access.
 - Top Clearance – 200mm (8") from ceilings or overhead cable trays/ducting, required for optimum system cooling.
 - Single Side or Back Clearance – 600mm (24") from walls and other equipment recommended to assist access.
 - Back Clearance – 600mm (24") from walls if the vented back panel is fitted.

Step 2 - Unpack the power system



- 1 Before the dc power system is unpacked, ensure that:
 - The site has been thoroughly cleaned and is dust free. (It is strongly recommended that you do NOT unpack the power system until all building work at the site has been completed. If building work is still in progress, store the power system in its original packaging in a dry and level location inside the building.)
 - Lifting equipment and at least two people are available. (Without lifting equipment four people are required to move the power system safely.)
- 2 When the site is clean and dust free, remove the packaging from the power system and stand the rack upright.
- 3 Carefully inspect the power system for possible damage that may have occurred while in transit. Report any damage immediately, using a completed Equipment Incident Report on page [101](#).


Step 3 - Fix the cabinet(s) directly to the floor (if required)



Ignore this Step if the site has a raised floor.

- 1 Mark the positions of fixing holes on the floor using the following template. Allow for the required clearances (see Step 1).
- 2 Drill the mounting holes. Remove any shavings and dust.
- 3 Before moving the cabinet(s), ensure that:
 - protective floor coverings are in place (if required)
 - the floor can support the weight of the power system.
- 4 Move the cabinet(s) into position.

Use lifting equipment and at least two people (or four people without lifting equipment) to move a power system safely.
- 5 Bolt the cabinet(s) to the floor using fasteners to suit the weight of the cabinet and type of floor.



① Recommended fixing holes. Remove cabinet side panels to access.

② Alternate fixing holes. Bottom rectifier magazine must be removed to access front two holes.

Step 4 - Fix the cabinet(s) on a raised floor (if required)



Ignore this Step if the cabinet is fixed directly to the floor.

- 1 Assemble the plinth(s) (Eaton part number: PLINIR-A00).
- 2 Remove the appropriate floor tile(s).
- 3 Fix the plinth(s) to the floor support pillars.
- 4 Before moving the cabinet(s), ensure that:
 - protective floor coverings are in place (if required)
 - the floor can support the weight of the power system.
- 5 Move the cabinet(s) into position on the plinth.
 - Use lifting equipment and at least two people (or four people without lifting equipment) to move a power system safely.*
- 6 Bolt the cabinet(s) to the plinth(s) using bolts supplied.

Procedure complete

Task 3 - Connect the Output to Earth

Step 1 - Connect dc common busbar to earth




Install a separate conductor from the dc common busbar to the customer dc earth. This conductor must be rated to carry the combined fault current of all battery strings.

- If this conductor is not installed then battery fault current will be carried by the ac-dc earth link and the ac earth conductor which are typically too small for such currents.*

Step 2 - Check ac-dc Earth Link



A 50 mm² yellow/green ac-dc earth link is factory fitted in the dc power system as shown in the following diagram.



If your installation uses a mesh earth, then Eaton recommends that this factory fitted ac-dc earth link is retained. No further action is then required (ignore Step 3). However, if your policy is not to bond the ac/communications earth and dc earth, then go to Step 3.


Step 3 - Remove or replace the ac-dc Earth Link (if required)



Ignore this Step if the factory fitted ac-dc earth link is used.


There are two options if the ac-dc earth link cannot be retained. Either:

- If the site surge protection is designed to limit transient ac earth - dc earth voltages to less than 1500V at the dc power system, then remove the ac-dc earth link.



- Or, if the site surge protection is not designed to limit transient ac earth - dc earth voltages to less than 1500V at the dc power system, then replace the ac-dc earth link with a surge protection device.

The transient protective device bonds the ac and dc earths during transient activity to prevent damage to the rectifiers. The preferred transient protective device is a transient earth clamp (TEC).



The path between ac earth and dc common bus (via the transient earth clamp) must be as short and straight as possible, preferably less than 500mm (20").

The transient earth clamp must have the following minimum specifications.

- Nom. dc Spark-over Voltage 600V
- Impulse Spark-over Voltage at 1 kV/μs < 1400V
- Nom. Impulse Discharge Current - 8/20μs wave shape 20kA
- Insulation Resistance at 100V $\geq 10^{10} \Omega$
- Capacitance < 1.5pF

A larger transient earth clamp with a high kA rating must be used if the potential severity of a lightning strike is high.

Procedure complete

Task 4 - Connect the DC Load Cables

A wide range of dc distribution modules is available for Data-Voice-Video 3G Power Solutions with MCBs or fuses or both.

Step 1 - Access MCBs and/or fuses




See the diagram on page [2](#) for location of the dc distribution with the load MCBs/fuses.

Step 2 - Connect load cables to load MCBs (if required)



Ignore this Step if the dc distribution does not have load MCBs.

- 1 Switch off all load MCBs.
- 2 Terminate the load live cable(s) at the load MCB(s).
 - ☐ The current rating of the MCBs must be derated to 80%.
 - ☐ Refer to the table of minimum cable sizes for specific MCBs on page [75](#).
 - ☐ Ensure that the fuse fail detection wires are properly terminated as shown.
- 3 Terminate the load common cable(s) at the dc common bar.




- ① Load MCB
- ② Load live cable
- ③ Fuse fail detection wire

Step 3 - Connect load cables to load fuses (if required)



Ignore this Step if the dc distribution does not have load fuses.

- 1 Remove all load fuse links.
- 2 Terminate the load live cable(s) at the load fuse(s).
 - ☐ The current rating of the fuses must be derated to 75%.
 - ☐ Refer to the table of minimum cable sizes for specific fuses on page [75](#).
 - ☐ Ensure that the fuse fail detection wires are properly terminated as shown.
- 3 Terminate the load common cable(s) at the dc common bar.



- ① Load fuse link
- ② Load live cable
- ③ Fuse fail detection wire

Procedure complete

Task 5 - Connect Battery Cables (if required)

Ignore this task if the dc power system is a single cabinet with integrated battery shelves (no separate battery cabinets or racks).

There are two options for the connection of battery cables from a separate battery cabinet or rack:

- 1 Connect battery cables direct to bus bars (via LVD if fitted) in the dc power system cabinet.
 - ☐ *Battery MCBS or fuses must be fitted at the separate battery cabinet or rack to protect the battery cables.*
- 2 Connect battery cables to MCBS or fuses in the dc power system cabinet.

Step 1 - Connect battery cables direct to bus bars (if required)



Ignore this Step if the dc distribution has battery MCBS or fuses (go to Step 2). See the diagram on page [2](#) for location of the dc distribution.


- 1 Switch off all battery MCBS or remove fuse links to isolate the batteries.
- 2 Route the battery cables to the dc power system.
- 3 Terminate the battery live cable(s) at the battery bus bar.
- 4 Terminate the battery common cable(s) at the common bus bar.
- 5 Secure all cables to prevent strain on the terminals.

Step 2 - Connect battery cables to battery fuses (if required)



Ignore this Step if the dc distribution does not have battery fuses. See the diagram on page [2](#) for location of the dc distribution.

- 1 Remove all battery fuse links.
 - ☐ *Ensure that the fuse fail detection boards are fitted as shown. (When a fuse link is replaced ensure the board is removed from the blown fuse and re-fitted to a new striker type fuse link).*
- 2 Terminate the battery live cable(s) at the battery fuse(s).
 - ☐ *The current rating of the fuses must be derated to 75%.*
 - ☐ *Refer to the table of minimum cable sizes for specific fuses on page [75](#).*
- 3 Terminate the battery common cable(s) at the dc common bar.



- 1 Battery fuse link (striker type)
- 2 Battery live cable
- 3 Fuse fail detection board

Step 3 - Connect battery cables to battery MCBs (if required)



This Step only applies to a rectifier cabinet without integrated battery shelves. Ignore this Step if the dc distribution does not have battery MCBs. See the diagram on page [2](#) for location of the dc distribution.

- 1** Switch off all battery MCBs.
- 2** Terminate the battery live cable(s) at the battery MCB(s).
 - The current rating of the MCBs must be derated to 80%.*
 - Refer to the table of minimum cable sizes for specific MCBs on page [75](#).*
- 3** Terminate the battery common cable(s) at the dc common bar.

Procedure Complete

Task 6 - Install the Batteries



- Always check that the battery cables have been terminated to the correct system polarity BEFORE connecting the batteries or closing the battery disconnect device.
- Connecting batteries to the system with incorrect system polarity will void all warranty claims.
- See Warnings on page [12](#).

The following are recommended Battery Installation Practices. These supplement any specific installation instructions from the battery manufacturer.

General

- Do not wear a synthetic dust-coat or overalls. Synthetic fabrics can hold a static electric charge, creating sparks during discharge.
- Remove rings, wristwatch and other metal jewelry that might be exposed to battery terminals, before installing batteries.
- Only use a clean soft damp cloth for cleaning the batteries. Do not use cleaning detergents or chemicals.
- Flooded cell and VRLA lead acid batteries can emit explosive gases and must be installed with adequate ventilation. Refer to the battery manufacturer or supplier for advice on minimum ventilation levels.
- Ensure that the battery strings are disconnected from the dc power system, by switching off all battery MCBs or removing all battery fuses.

Unpacking and Inspecting the Batteries

- Unpack the batteries and inspect them carefully for leaks, corrosion and possible damage. Report any damage or other battery related problems immediately to the battery supplier.
- Do not remove the factory-fitted transit insulation covers from the batteries until access to the battery terminals is required.

Connecting the Batteries


- Only terminate battery cables and interconnecting bars after confirming that the termination will not create a short circuit.
- Always use insulated tools.
- Always tighten battery terminal bolts according to the battery manufacturer's specification. Failing to do so can cause erratic battery performance, possible damage to the batteries, and/or personal injury.
- Do not place tools, loose cables, or metal objects (such as interconnecting bars) on top of batteries.
- Do not drop tools, loose cables, or metal objects onto intercell connections or terminals of opposite polarity.
- Check that loose cables cannot make contact with other cables or terminals which may be live.

Installation procedure

The following procedure applies to batteries installed in the Data-Voice-Video 3G Power Solutions integrated battery shelves or the optional additional battery racks only. For batteries installed in separate battery racks consult the manufacturer's installation instructions.

Notes:

- 1 Check that loose cables cannot make contact with other cables or terminals which may be live.
- 2 Always equip the lowest battery shelf in a rack first to ensure rack stability.
- 3 The following order of connection must be followed.



Typical battery arrangement (-48V)

Step 1 - Inspect first (lowest) battery shelf and prepare cables



- 1 Remove the battery shelf front cover.
- 2 Check the first (lowest) battery shelf in the rack is clean and clear of obstruction.
- 3 Pull both cables to the front of the rack in preparation for fitting the batteries.
- 4 Check the battery MCB is OFF.
- 5 If required, route one of the Battery Mid-point Monitoring sense wires from XH12A on the input/output board (see location on page 2) to the battery shelf (SC200 only).
 - Connect the wire from XH12A pin 1 to string 1, and so on.

Step 2 - Fit the batteries



- 1 Slide a battery to the left hand side of the shelf (position 1).
 - Use a suitable mechanical lifting aid to fit batteries in the rack.
- 2 Slide another battery to the right hand side of the shelf (position 4).
- 3 Slide the third battery next to the battery on the left hand side (position 2).
- 4 Slide in the last battery (position 3).

Step 3 - Connect cables




- 1 Connect the positive battery cable to the positive terminal of the battery in position 4.
- 2 Tighten the bolt on the battery terminal to the torque recommended by the battery manufacturer.
- 3 Connect the negative battery cable (connected to the MCB) to the negative terminal of the battery in position 1.
- 4 Tighten the bolt on the battery terminal to the torque recommended by the battery manufacturer.
- 5 Check that the battery terminal connections are not touching metalwork and that there is a sufficient gap between the terminals and the rack sides. Do not proceed until this has been checked and corrected if necessary.

Step 4 - Interconnect batteries



- 1 Remove the covers from batteries 3 and 4.
- 2 Connect the first interconnecting link between the positive (+ve) terminal of battery 4 and the negative (-ve) terminal of battery 3.
- 3 Adjust the battery positions so that the connection places no strain on the terminal screw in any direction.
- 4 Tighten according to the manufacturer's recommended torque settings.
- 5 Replace the cover on battery 4.
- 6 Repeat procedure for batteries 2 and 3, and connect the Mid-point monitoring sense wire (SC200 only).
- 7 Repeat procedure for batteries 1 and 2.



Step 5 - Check voltage and polarity



- 1 Remove the covers from batteries 1 and 4.
- 2 Check with a voltmeter that the negative terminal of battery 4 is more than 48V negative of the positive terminal of battery 1.
- 3 Check all terminal covers are in place.

Step 6 - Check terminals



Check that the battery terminal connections are not touching metalwork and that there is a sufficient gap between the terminals and the rack. Do not proceed until this has been checked and corrected if necessary.

Step 7 - Install remaining batteries



- 1 Repeat the above procedure for the remaining battery shelves to be populated. Work from the bottom to top shelf.
- 2 Repeat for additional battery racks if required.

Step 8 - Insulate any unconnected sense wires (SC200 only)



Insulate and secure any un-connected Battery Mid-point Monitoring sense wires.

Step 9 - Replace the battery shelf front cover(s)



Procedure complete

Task 7 - Mount the Battery Temperature Sensor

The DV2-3G is supplied with a battery temperature sensor and standard 8m (26 feet) long RJ45 cable, already connected to the IOBGP input/output (I/O) board to measure the ambient air temperature around the batteries. This is required for the temperature compensation control process.

Step 1 - Connect and route cable



- 1 Connect the temperature sensor cable supplied to socket XH7 on the I/O board.
 - ☐ If required extend the cable using an RJ45 patch cable and in-line joiner. Recommended maximum cable length is 20m (65 feet) because of noise considerations.
- 2 Route the temperature sensor cable to the middle battery shelf or the middle of the external battery stand.
 - ☐ Do not run the sensor cable along ac supply cables. Interference may cause false readings.

Step 2 - Fix sensor

Fix the sensor above the batteries. To avoid false readings:

- Do not attach the sensor to a battery case, battery cables, terminals or interconnecting bars.
- Do not expose the sensor to direct sunlight, or air movements from air-conditioning systems or open windows.

Procedure complete**Task 8 - Connect External Current Sensors/Shunts (if required)**

External current shunts/sensors are connected to the system controller either directly (depending on the number of internal current shunts/sensors fitted) or through a SiteSure-3G module.

See External Current Shunts/Sensors on page [83](#) for further installation information.

Refer to the System Controller Operation Handbook for details of connection of external current shunts/sensors. See Related Information.

See Connect Additional Input/Output on page [32](#) for information on installing SiteSure-3G modules.

Task 9 - Connect Input/Output Cabling (if required)

Refer to Input/Output Board on page [6](#) for details of how the I/O board can control and monitor external devices.

If no external devices are to be connected then ignore this task.

Step 1 - Route cable to the I/O board

See the diagram on page [2](#) for the location of the I/O board.

Step 2 - Terminate the cabling

- Connect only voltage-free switch or relay contacts to Digital Inputs.
- Do not exceed the voltage and current limits of the relay contacts.
- For wire size and I/O ratings see Specifications on page [73](#).

- 1 Terminate the cable as in the diagram on page [6](#).
- 2 Use cable ties to secure the cable and prevent strain on the connectors.

Step 3 - Set up SC200 or SC100

Configure the inputs and outputs after completing the installation and all the Startup Tasks on page [38](#).

□ For configuration details refer to *Digital Inputs and Digital Outputs in the System Controller Operation Handbook* (see Related Information).

Procedure complete

Task 10 - Connect Additional Input/Output (if required)

If additional input/outputs are required then SiteSure-3G modules can be connected to the dc power system. A SiteSure-3G input/output module has the following features:

Digital Inputs:	10
Digital Outputs (relays):	6
Analog Inputs (-10V to +10V):	4
Current Sense Inputs:	3
Temperature Sense Inputs:	2
Bus Voltage Input (0-60V):	1
Enclosure:	Wall or panel mounting plastic case

Use the following procedure to connect a SiteSure-3G input/output module, if required.

Step 1 - Route and connect cable to DV2-3G



- 1 Route an RJ45 patch cable from the SiteSure-3G module to the DV2-3G.
- 2 Connect the cable to an RJ45 socket (S1, S2 or S3) on the Voltage Feed Module board via an RJ45 splitter. See the diagram on page 7 for socket location.
- 3 Use cable ties to secure the cable and prevent strain on the connectors.
- 4 Test the insulation and continuity of the conductors.

Step 2 - Connect the cable to socket YH11 on the SiteSure-3G module



Procedure complete

For details on setup refer to the SiteSure-3G Installation Guide. See Related Information.

Task 11 - Connect Battery Fuse Fail (if required)



This Task only applies to a system with one or more additional battery cabinets with MCBs.


Step 1 - Connect battery MCB fuse fail detect wires (if required)



Use 2-core 0.5mm² flex (or similar) to connect from the terminal block in the battery cabinet to the auxiliary switch on the first battery MCB in the rectifier rack (see following diagram).



All auxiliary switches are connected in parallel. The auxiliary switch contacts will close when an MCB is OFF.



- ① Rectifier cabinet with integrated battery shelves.
- ② Additional battery cabinets with MCBs.
- ③ Battery MCB fuse fail detect wires connected to terminal block in the battery cabinet.
- ④ Fuse fail detect board in Rectifier cabinet.
- ⑤ Fuse fail detect wires to other battery MCBs.
- ⑥ Connection to other battery cabinets (if required).

Step 2 - Connect to other battery cabinets (if required)



Extend the wiring to the terminal block(s) in any additional battery cabinets.

Procedure complete

Task 12 - Connect to the AC Supply




- If the dc power system is to be installed in a location where the ambient temperature may rise above 50°C (122°F), then 105°C rated cable rated cable must be used for all connections.
- Only use a three-phase (Δ) ac supply that is referenced to earth, or has a protection system in place to prevent the phase-earth voltage exceeding the rating of the rectifier.

Step 1 - Access ac MCBs (systems with integrated battery shelves)



Ignore this Step if system does not have integrated battery shelves (go to Step 2).

- 1 The ac MCBs are fitted in the combined ac and dc distribution section. See the diagram on page 2 for location. The layout of the ac MCBs is shown in the following diagram.
- 2 To access the MCBs:
 - Open ac/dc distribution space door.
 - Switch the ac isolator to the OFF position.
 - Undo the four screws securing the Perspex cover and remove the cover.
- 3 Go to Step 3.



Typical arrangement with Neutral

- ① Earth cable to rack earth stud.
- ② Phase and Neutral (if fitted) cables.
- ③ AC isolator switch (1, 2 or 3-phase as required). May be fitted next to MOVs depending on model.

Typical arrangement without Neutral

- ④ Rectifier or magazine MCBs (arrangement depends on model)
- ⑤ Surge protection MOVs (2, 3 or 4 as required).
- ⑥ AC earth termination point.


 *Other cables not shown for clarity.*

Step 2 - Access ac MCBs (systems without integrated battery shelves)



Ignore this Step if system has integrated battery shelves (see Step 1).

- 1 The ac MCBs are fitted in the ac distribution. See the diagram on page 2 for location. The layout of the MCBs is shown in the following diagram.
- 2 To access the MCBs:
 - Switch the isolator to the OFF position.
 - Undo the four screws holding the front panel.
 - Remove the front cover and isolator switch handle.



① AC isolator switch (shaft not shown)	⑤ Rectifier MCBs (3 only shown)
② Neutral bar termination (if fitted)	⑥ Surge protection MOVs
③ AC cable entry glands	⑦ MOV MCB (located next to MOVs in some models)
④ Isolator switch terminals	

Step 3 - Check the connection of the ac terminals



Check the ac terminals on the DV2-3G are connected to suit the type of ac supply. Data-Voice-Video 3G Power Solutions dc power systems can only be connected to one of the following:

AC source	Voltage (nominal)*	AC MCB (if fitted)
1-phase, neutral and Protective Earth (PE)	220-240V phase-neutral	1-pole
2-phase and PE	208V phase-phase	2-pole (linked)
3-phase, neutral and PE	220-240V phase-neutral	3-pole
3-phase and PE	208V phase-phase	3-pole (linked)



*See *Specifications* on page [69](#) for the ac voltage range and ac input current.

Step 4 - Prepare the ac supply cable



- 1 Select ac supply cable to suit the ac supply source, the maximum ac current (see Specifications on page [69](#)) and in accordance with the local wiring regulations.
- 2 Route the ac supply cable from the ac supply point into the top or bottom of the cabinet as required.
Do not terminate at the ac supply point at this stage.
- 3 At the DV2-3G, cut the conductors to suit the positions of the ac MCB(s).
 - Ensure the earth conductor is 30-50mm (1¼ - 2 inches) longer than the longest phase or neutral conductor.*

Step 5 - Terminate the earth conductor at DV2-3G



- 1 Terminate the earth conductor with an M6 (1/4") crimp lug.
 - Ensure the ferrule of the crimp lug covers all strands of wire.*
- 2 Connect the earth conductor to the ac earth termination point.

Step 6 - Terminate the phase and neutral (if used) conductor(s) at DV2-3G



- 1 Connect the phase conductor(s) to the MCB(s).
- 2 If fitted, terminate the neutral conductor with an M4 (3/16") crimp lug and connect to the neutral terminal or neutral bar.
 - Ensure the ferrules of the crimp lug covers all strands of wire.*

Step 7 - Connect at the ac supply point



- 1 Check the ac supply point is isolated.
- 2 Connect the cable to the ac supply point.
 - Follow the manufacturer's instructions and local wiring regulations.*
- 3 Label the connection at the ac supply point.

Step 8 - Check terminations, secure cables and test insulation



- 1 Check all terminations are correct and are tightened.
- 2 Secure the cable with cable ties to ensure there is no strain on terminals.
- 3 Test the insulation resistance of the conductors according to local ac wiring regulations.
- 4 Replace all covers/panels.

Procedure complete

Installation Completed

Installation of the DV2-3G is now complete. Follow the instructions in Start-Up on page [38](#) to make the system operational.

Overview

Topic	Page
Start-Up Tasks	<u>38</u>
Task 1 - Inserting the Rectifiers	<u>38</u>
Task 2 - Pre-Power-Up Checklist	<u>39</u>
Task 3 - Applying AC Power	<u>39</u>
Task 4 - Configuring the DC Power System	<u>40</u>
Task 5 - Apply DC Power to Battery and Load	<u>41</u>
Start-Up Completed	<u>42</u>

Start-Up Tasks

Complete all the Installation tasks (see details) before starting these Start-Up tasks.

Complete the Start-Up tasks in the following order:

Task	Description	Reference
1	Insert the Rectifiers	See details on page 38
2	Complete the Pre-Power-Up Checklist	See details on page 39
3	Apply AC Power	See details on page 39
4	Configure the DC Power System	See details on page 40
5	Apply DC Power to Battery and Load	See details on page 41

Task 1 - Inserting the Rectifiers



- Do NOT install the rectifiers until the room has been cleaned and is dust free.
- Do NOT switch on the ac supply at this stage.

Step 1 - Unpack the rectifiers



Unpack the rectifiers and inspect them carefully for possible transport damage. Report any damage immediately using a completed Equipment Incident Report on page [101](#).




Keep the original packaging to return a rectifier for replacement or repair, if required.

Step 2 - Fit first rectifier



- 1 Align the rectifier with the left side of the shelf.
- 2 Push in the rectifier until the retaining screw contacts the shelf.
- 3 Check the rectifier's rear connector is correctly aligned with the shelf connector or damage may occur.
- 4 Tighten the retaining screw to 1.5Nm (13.3 inch-pounds). This will locate the rectifier in its rear connector.



Step 3 - Repeat for other rectifiers or fit blank panels

- 1** Fit the rectifiers in positions 1-4-7-2-5-8-3-6-9-10 to balance the load on the three ac phases.
- 2** Fit rectifier blank panels in any vacant rectifier positions.

Procedure complete**Task 2 - Pre-Power-Up Checklist**

Complete the checklist to confirm initial work is complete before progressing further.



- All cabling is installed, securely tied and correctly insulated
- Upstream surge protection is fitted (see Input Transient Protection on page [85](#))
- Earth bonding is correct (see details on page [22](#))
- Battery and load cabling has the correct polarity
- A registered electrician or other suitable approved person has checked the integrity of the installed cabling
- All panels are in place and all empty rectifier slots are covered with blanking panels
- AC isolator and all ac MCBs are switched off
- All dc distribution MCBs are switched off and/or fuses removed
- AC supply is isolated at each point of isolation leading back to the ac supply point
- Batteries are electrically isolated from the dc power system
- The site is clean

Task 3 - Applying AC Power

- A registered electrician (or suitably qualified person) must check the integrity of the installed cabling, BEFORE the dc power system is powered up.

- 1** Ensure all ac MCBs are off.
- 2** Switch on the ac supply.
- 3** Switch on the ac MCB (or the first, if more than one).
 - Rectifier(s) start up (after the startup delay).
 - The rectifier alarm LEDs will turn on for a short time.
 - The SC200 or SC100 system controller will turn on (green Power On LED is on) when dc power is available from the rectifier(s).
 - During start-up of the SC200 or SC100 system controller, the yellow alarm LED on the rectifier(s) will flash until rectifier registration is completed.

- 4 After start-up of the SC200 or SC100:
 - Press any key to silence the alarm.
 - *Depending on the configuration file settings, the alarm LED(s) may be on and the SC200 or SC100 will display some system alarm messages. This is normal. For an explanation of alarm messages see Alarm Descriptions in the System Controller Operation Handbook.*
 - The LCD module shows the default screen. See details on page [45](#).
 - *If no load or battery is connected the current will be 0A.*
 - If fitted and enabled, the LVD(s) operate.
- 5 Check for correct operation of the rectifier(s). Check only the green Power On LED(s) are on (no alarm LEDs).
 - Use the SC200 or SC100 keypad to check that all rectifiers are registered. See details in the System Controller Operation Handbook.
- 6 If any problems see Troubleshooting on page [52](#). Otherwise switch on all remaining rectifiers.

Task 4 - Configuring the DC Power System

The operational settings of the dc power system are stored in a configuration file loaded into the SC200 or SC100 system controller. See details on page [44](#).

The system controller is supplied pre-loaded with a configuration file. If this configuration file has been customized for the site then no further configuration changes will be necessary.

If the configuration file has not been customized for the site, then check the following settings and change if necessary.

- *Other configuration settings can be changed after all Start-Up tasks are complete. Refer to the System Controller Operation handbook (see Related Information) for details on how to customize the system's configuration.*

Parameter	Action	Where to find	
Float Voltage	Set to the value recommended by the battery manufacturer.	SC100:	Menu > Configuration > System > Edit > Float Voltage
		SC200:	Control Processes > Voltage Control > Float Voltage
		DCTools:	Control Processes > Voltage Control > Float Voltage
Battery Capacity	Set to the rated 10 hour capacity of the installed battery strings, or set to zero if no battery connected.	SC100:	Menu > Configuration > System > Edit > Battery Capacity >Edit
		SC200:	Battery > Battery > Battery Capacity
		DCTools:	Batteries
Cells Per String	Set to the number of cells in each battery string (if battery connected).	SC100:	Menu > Configuration > Temp Compensation > Edit > Cells Per String
		SC200:	Battery > Battery > Cells Per String
		DCTools:	Batteries

Parameter	Action	Where to find	
Temperature Compensation	Enable (if battery and battery temperature sensor connected) and check the settings.	SC100:	Menu > Configuration > Temp Compensation > Edit
		SC200:	Control Processes > Temp. Compensation > Enable
		DCTools:	Control Processes > Temperature Compensation
Low Voltage Disconnect (LVD)	Enable (if LVD(s) installed and battery connected) and check the settings.	SC100:	Menu > Configuration > LVD1/LVD2
		SC200:	Battery > LVDs > LVD x
		DCTools:	Control Processes > LVD
System controller time (SC200 only)	Connect using Web to set correct time manually or connect using DCTools to synchronize to PC time. See details in the System Controller Operation Handbook.	Web:	Configuration > Time
		DCTools:	Configuration > Time > Time Synchronization

Task 5 - Apply DC Power to Battery and Load



Reverse Polarity

- Always check that the battery cables have been terminated to the correct system polarity BEFORE connecting the batteries or closing the battery disconnect device. Connecting batteries to the dc power system with incorrect system polarity will damage the rectifiers and void all warranty claims.

Step 1 - Check dc voltage and polarity



Check the dc output voltage and polarity of the power system and the battery string(s).

Step 2 - Connect batteries



- If connecting multiple battery strings then check the individual strings are of similar voltage.
- Switch on all Battery MCB(s) and/or fit the battery fuses.
- Check the Battery Fuse Fail alarm clears.
 - All Battery MCBs (including any unused MCBs) must be switched on to clear the alarm.*
- Check the battery current. The actual value depends on the state of charge of the batteries.

Step 3 - Connect load



- Switch on the Load MCB(s) and/or fit the Load fuses.
- Check the equipment powers up and the Load Fuse Fail alarm clears.

Step 4 - Check the rectifier currents



- 1** Check the rectifier currents.
- 2** Verify the load current is as expected for the load and battery size and does not exceed the maximum load rating (see details on page [69](#)).

Step 5 - Charge the batteries



- 1** Charge the batteries according to the battery manufacturer's recommendations.
- 2** If an Equalize charge is recommended by the battery manufacturer then follow the instructions in the System Controller Operation Handbook for details (see Related Information).
 - *Equalize increases the system voltage to the Equalize voltage for the Equalize duration. After the Equalize duration has expired, the dc power system voltage reverts to float voltage automatically.*

Procedure complete

Start-Up Completed

Start-Up of the DV2-3G is now complete and the system is operational.

If a formal commissioning test is required then see the Commissioning check lists on page [89](#).

The System Controller Operation Handbook (see Related Information) describes how to use the SC200 or SC100 system controller. See:

- *System Operation* to customize the system configuration settings, and
- *Communications* to setup the remote communications options.

For information on alarms, or operation problems see Maintenance on page [51](#).

System Controller

Topic	Page
Configuration File	<u>44</u>
Starting the SC200 or SC100	<u>45</u>
SC200 or SC100 Operation using the Keypad and Screen	<u>46</u>
SC200 or SC100 Operation Using a PC/Laptop	<u>48</u>
SC200 or SC100 Identity Information	<u>50</u>

Configuration File

The operational settings of the dc power system are stored in a configuration file loaded into the SC200 or SC100 system controller.

The SC200 or SC100 is supplied pre-loaded with a configuration file. If this configuration file has been customized for the site then no further configuration changes will be necessary.

Otherwise, it is important that the settings of this configuration file are checked and changed as required for site-specific conditions. In particular, settings that may affect the performance and life expectancy of the battery must be checked and set according to the battery manufacturer's recommendations.

Some settings in the configuration file can be edited using the system controller's keypad (see details on page [46](#)), or all settings can be edited using a PC/laptop with DCTools (see details on page [48](#)) or remotely, see Communications Options in the System Controller Operation Handbook.

Backup and Restore

The configuration file settings in the SC200 or SC100 can be saved to (Backup) or loaded from (Restore) a PC/laptop using DCTools.

Backup and Restore can be used to:

- Load a standard (master) configuration file into an SC200 or SC100 for customization.
- Copy a customized configuration file from one SC200 or SC100 to others (at similar sites).
- Save a copy of a customized configuration file. This is recommended in case the SC200 or SC100 has to be replaced.

► To use DCTools for Backup and Restore

- 1 Connect to the SC200 or SC100 with DCTools. See Communications Options in the System Controller Operation Handbook.
- 2 In DCTools go to *File > ICE Backup/Restore* and follow the prompts.
 - *The saved file does not include site specific settings including Site Identity, IP Address, S3P Address, battery characterization data.*

► To use a web browser for Backup (SC200 only)

- 1 Connect to the SC200 via a web browser. For details see Ethernet Communications in the System Controller Operation Handbook.
- 2 Go to *Tools*.
- 3 Select *Backup Tool*.
- 4 Select the file type:
 - **System Snapshot (*.dcs):** Configuration file including site specific settings.
 - **Configuration (*.dcc):** Configuration file without site specific settings - Site Identity, IP Address, S3P Address, battery characterization data).
- 5 Click *Proceed* to Backup the configuration.


► **To use a web browser for Restore (SC200 only)**

- 1 Connect to the SC200 via a web browser. For details see Ethernet Communications in the System Controller Operation Handbook.
- 2 Go to *Tools*.
- 3 Select *Restore Tool*.
- 4 Select the file type:
 - **System Snapshot (*.dcx)**: Configuration file including site specific settings.
 - **Configuration (*.dcc)**: Configuration file without site specific settings - Site Identity, IP Address, S3P Address, battery characterization data).
 - **Fragment (*.dcf)**: Restore part of a configuration file (such as battery characterization data).
- 5 Click *Next*, and then select a file name to *Restore* a configuration.

Starting the SC200 or SC100

When dc power is applied to the SC200 or SC100 (via the RXP connector YS11) the start-up sequence begins.


SC200



See navigation details on page [77](#).


If Logon is required see Keypad Access Security on page [46](#).

SC100



See details on page [78](#).

SC200 or SC100 Operation using the Keypad and Screen



Keypad Access Security

SC200 System Controller

This feature prevents accidental or unauthorized changes to settings from the SC200 keypad.



All access to change an SC200's settings will be lost if:

- All communications are disabled (see S3P Access and HTTP/HTTPS Access in the System Controller Operation Handbook), and
- Keypad access is *Read Only*, or *PIN Protected* and the keypad access PIN is lost.

The SC200 will continue to function, but no configuration changes can be made. Contact your Eaton dc product supplier or Eaton for advice (see Worldwide Support on page [103](#)).

- ▶ **To use DCTools to enable/disable keypad access**
 - In DCTools go to *Communications > Front Panel*.
 - Set *Access* to:
 - *Unprotected* - keypad access is allowed to view and change parameters, or
 - *Read Only* - keypad access is allowed to view parameters only, or
 - *PIN Protected* - keypad access is allowed to view and change parameters if the correct 4-digit number is typed in the *Access PIN* field. Otherwise, *Read Only* access is allowed.
- ▶ **To use the SC200 when access is set to PIN Protected**
 - At the Main Screen press *Menu*. The *Logon* screen appears.
 - If the *Access PIN* is not known then press *Skip* to use the SC200 with *Read Only* access.
 - If the *Access PIN* is known:
 - Use the Left and Right keys to access each digit position. Use the Up and Down keys to change the digits.
 - When the correct digits are entered, press *Logon*.

 Keypad access will return to PIN Protected mode when the display returns to the Main Screen.

SC100 System Controller

This feature prevents accidental or unauthorized changes to settings from the SC100 keypad.

► **To use DCTools to enable/disable keypad access**

- In DCTools go to *Communications*.
- Set *UI Access* to:
 - *Unprotected* - keypad access is allowed, or
 - *Protected* - keypad access is denied (can be temporarily over-ridden, see below).

► **To temporarily enable keypad access at the SC100 when access is set to Protected**

- Press *Up* and *Down* keys together for 5 seconds.

 *Keypad access is now temporarily enabled. Keypad access control reverts back to Protected mode after the display goes back to the Summary screen.*

Alarm Indicators

Visual indicators



Power on LED (green)



Minor Alarm LED (yellow)



Critical/Major Alarm LED (red)



The system value cannot be displayed because of a failed, disconnected or unconfigured sensor.

Audible indicator

- One beep – indicates an invalid key press
- Three beeps every 2 seconds – refer to the alert message on the display (SC200 only)
- One beep every 2 seconds – Minor alarm is active
- Continuous sound – Critical/Major alarm is active

 *Critical/Major alarms always override Minor alarms.*

► **To stop the audible indicator**

- Press any key

 *The audible indicator will restart at the next active alarm or alert message.*

► **To enable/disable the audible alarm indicator**

Either:

- On SC200 go to: Alarms > Alarm Settings > Audible Alarms > Edit.
- or on SC100 go to: Menu > Configuration > Audible Alarm.

Or:

- In DCTools go to: *Alarms > Alarm Configuration*.

 *When Disabled, the audible indicator will still indicate an invalid key press.*

SC200 or SC100 Operation Using a PC/Laptop

DCTools is configuration software for editing a system controller's configuration file (on-line) and monitoring the operation of Eaton's dc power systems. It is available free from dcpower.eaton.com/downloads.

Using DCTools via USB (SC200 only)

DCTools can be run on a PC/laptop connected to the SC200's USB port.

 *DCTools can also be run on a remote PC/laptop connected to the SC200's RS232 serial port (via a modem) or Ethernet port. For remote PC/laptop connection details see Communications Options in the System Controller Operation Handbook.*

Before you start you will need:

- The latest version of *DCTools* available from dcpower.eaton.com/downloads.
- A PC/laptop with USB port and USB A/B cable (RadioShack 55010997, Jaycar WC7700, or equivalent).

► **To connect a PC/laptop to the SC200:**

- 1 Download the latest version of *DCTools* from dcpower.eaton.com/downloads.
- 2 Install *DCTools* on the PC/laptop.
- 3 Connect a USB A/B cable from a USB port on the PC/laptop to the USB port on the SC200.
 *See the diagram on page 4 for location of the USB port.*
- 4 *DCTools* will now connect to the SC200.
 *If connection is not successful refer to *DCTools Help* (press F1) or *Troubleshooting* on page 52.*
- 5 For details of the SC200 control and monitoring functions available via *DCTools* see *System Operation* in the System Controller Operation Handbook.
 *For help using *DCTools* press F1.*

Using DCTools via RS232

DCTools can be run on a PC/laptop connected to the SC200 or SC100's RS232 port.

 *For remote PC/laptop connection details see Communications Options in the System Controller Operation Handbook.*


Before you start you will need:

- The latest version of *DCTools* available from: dcpower.eaton.com/downloads.
- A PC/laptop with USB port (for use with SC200) or RS232 port (for use with SC100)


► **To connect a PC/laptop to the SC200 or SC100:**

- 1 Download the latest version of *DCTools* from: dcpower.eaton.com/downloads.
- 2 Install *DCTools* on the PC/laptop.
- 3 Connect a null-modem cable from the COM1 RS232 port on the PC/laptop to the RS232 connector on the SC200 or SC100.
 - Ensure the cable is secured so that no force is applied to the RS232 connector as this may damage the connector.
 - If COM1 port is not available or for more details see *Direct RS232 Communications in the System Controller Operation Handbook*.

- 4 Start *DCTools* to open the Connection List. Check the box for the COM1 connection.



- 5 *DCTools* will now connect to the SC200 or SC100.
 - If connection is unsuccessful refer to *DCTools* help (press F1) or Troubleshooting on page [52](#).
- 6 For details of the SC200 or SC100 control and monitoring functions available via *DCTools* see System Operation in the System Controller Operation Handbook.
 - For help using *DCTools* press F1.



SC200 or SC100 Identity Information

The following identity information is stored in the SC200 or SC100.

Parameter	Description	Where to find:
Serial Number	The SC200 or SC100 serial number (factory set).	SC100: Menu > Identity >SC100 Identity
Software Version (App Version)	The version of the embedded software in the SC200 or SC100 (factory set).	SC200: Settings > Info DCTools: Configuration > Identity > Software

If required, the following site specific information can be stored in the SC200 or SC100 to assist site management.

Parameter	Description	Where to find:
System Manufacturer	The manufacturer of the dc power system.	
System Type	The DV2-3G model number.	
System Serial Number	The DV2-3G serial number.	
System Location	Location of DV2-3G at the site.	
Site Name	Name of the site.	DCTools: Configuration > Identity
Site Address	Address of the site.	
Site Notes	Any notes relevant to site access, location or other matters.	
Contact	Contact name, phone number, and so on.	
Configuration Name	Reference name of the configuration file in the SC200 or SC100.	

Overview



- The DV2-3G contains hazardous voltages and hazardous energy levels. Before undertaking any maintenance task refer to the Warnings on page [12](#).
- If a maintenance task must be performed on a "live" system then take all necessary precautions to avoid short-circuits or disconnection of the load equipment, and follow any "live-working" instructions applicable to the site.
- Only perform the maintenance tasks described in the Maintenance chapter. All other tasks are classified as Servicing. Servicing must only be performed according to specific instructions and only by personnel authorized by Eaton. This includes disassembly and/or servicing of any modules.
- For further information on Servicing contact your local Eaton dc product supplier, or refer to the contact details on page [103](#).

Topic	Page
Troubleshooting	52
Replacing or Adding a Rectifier	56
Replacing or Adding a Load MCB	57
Replacing a Load or Battery Fuse Link	58
Adding a Load Fuse	59
Replacing the System Controller	59
Replacing the Input/Output Board	61
Monitoring and Replacing Transient Protective Devices	63
Battery Mid-point Monitoring (String Fail) Alarm (SC200 only)	63
Battery Disposal and Recycling	64

Troubleshooting

Use the table to troubleshoot minor installation and operational problems. For additional assistance see contact details on page [103](#). Return items for replacement or repair with a completed Equipment Incident Report on page [101](#).

Problem	Possible Cause	Required Action
SC200 or SC100 alarm.		See Troubleshooting in the SC200 or SC100 Operation Handbook.
All rectifiers are off (no LEDs on) and system controller display is blank.	AC supply to the system is off and the batteries are fully discharged or disconnected.	Restore ac supply.
Green LED of one or more rectifiers is off.	AC supply to rectifier(s) off or one or more phases are off.	Restore the ac supply.
	Rectifier(s) not fully inserted.	Insert rectifier and tighten retaining screw.
	Internal rectifier fault.	Remove the rectifier and insert another one in the same slot. If second rectifier fails to start then there is a fault with the rectifier position. Check ac connections. If the second rectifier operates normally, the first rectifier is faulty and must be returned for service.
All rectifier LEDs flash.	The rectifier <i>Identify</i> function.	Normal operation. See details in the System Controller Operation Handbook.
Rectifier yellow LED flashes	The system controller is starting.	Wait for system controller to complete start-up.
	Rectifier has not registered with the system controller.	Remove, and then re-insert the rectifier. Replace the rectifier with another rectifier. If second rectifier fails to register, then there is a fault with the rectifier position. Check rectifier comms bus wiring. If second rectifier registers, then first rectifier is faulty and must be returned for service.

Problem	Possible Cause	Required Action
Rectifier yellow LED on.	Rectifier power limit or current limit is active.	Power system is charging the batteries. If required, activate the Battery Current Limit control process.
	Load current exceeds the total rectifier capacity.	Install additional rectifiers.
	Rectifier temperature turndown is active due to low ac supply voltage or high ambient temperature.	Power system will return to normal operation when the ac supply voltage and/or ambient temperature are within the specified ranges. See Specifications on page 69 .
Rectifier red LED on.	System controller has shut down the rectifier. (Depending on model, rectifier may also click every 5-15 seconds.)	Normal operation. See Rectifier Shutdown in the System Controller Operation Handbook. If required, restart the rectifier.
	Very high or low ac voltage, or ac supply failed.	Power system will return to normal operation when the ac supply voltage is within the specified range. See Specifications on page 69 .
	DC overvoltage	Remove and re-insert rectifier(s) or shut down and restart using <i>DCTools</i> .
	Internal rectifier fault.	Replace the rectifier.
Low system output voltage (rectifiers not in current limit).	Rectifiers off.	Restore the ac supply.
	Temperature Compensation is active and the battery temperature is above the reference temperature.	None. This is normal operation (if batteries are connected). Disable Temperature Compensation if no batteries connected.
	Battery Test or Battery Characterization is active.	None. Output voltage will return to normal when Battery Test or Battery Characterization is completed.
	Incorrect float voltage setting at system controller.	Correct the float voltage setting of the system controller. Record new setting.
Low system output voltage and rectifier yellow LEDs are on (rectifiers are in current limit).	Load is too high for rectifier capacity.	Install additional rectifiers.
	Battery is recharging after ac supply failure.	Check battery has recharged within expected time.

Problem	Possible Cause	Required Action
High system output voltage.	Temperature Compensation is active and the battery temperature is below the reference temperature.	None. This is normal operation (if batteries are connected). Disable Temperature Compensation if no batteries connected.
	Equalize or Fast Charge is active.	None. Output voltage will return to normal when Equalize or Fast Charge is completed.
Incorrect float voltage setting at system controller.		Correct the float voltage setting of the system controller. Record new setting.
Faulty rectifier.		Locate the rectifier with the highest output current and remove this one first. If the first rectifier removed is not faulty, remove each of the remaining rectifier modules one at a time, until the faulty rectifier is found. (The output voltage returns to normal when faulty rectifier is removed.) Replace faulty rectifier with one that is working. Return the faulty rectifier for service.
System has no dc output (rectifiers are on).	Load fuse or MCB open.	Check for open fuse or MCB.
	LVD contactor has disconnected the load.	Use <i>DCTools</i> to check LVD is enabled and set to correct values. (LVD status LED on the I/O board is on when contactor is energized.) Check that the I/O board is connected (Power LED is on). Check that the LVD control and power cables connections on page 7 . Check the connections from the load bus to the LVD.
System has no battery input	Battery MCBS or fuses open.	Check for open battery MCBS or fuses.
	LVD has disconnected the battery because ac supply is off and the battery is fully discharged.	None. The battery will be automatically reconnected when the ac supply is restored.
	LVD contactor is open.	Use <i>DCTools</i> to check LVD is enabled and set to correct values. (LVD status LED on the I/O board is on when contactor is energized.) Check that the I/O board is connected (Power LED is on). Check that the LVD control and power cables are connected. See Connections on page 7 . Check the connections from the battery bus to the LVD.

Problem	Possible Cause	Required Action
String Fail Alarm (SC200 only)	The Battery Mid-point Monitoring system has detected a voltage imbalance in one of the battery strings.	See Battery Mid-point Monitoring on page 63 .
	A Battery Mid-point Monitoring sense wire is disconnected.	Check the sense wires.
I/O board Power/Comms OK LED is off	I/O board is not powered or faulty.	Check connection to YH3 on I/O board. See Connections on page 7 . Replace I/O board if faulty.
I/O board Power/Comms OK LED is flashing.	I/O board is responding to an <i>Identify</i> command from the SC200 or SC100.	None, this is normal operation. See details in the System Controller Operation Handbook.
LVD Status LED(s) (on I/O board) are on.	LVD contactor is energized.	None, this is normal operation.
LVD Status LED(s) are off (I/O board Power On LED is on).	LVD contactor is de-energized.	None, this is normal operation.
LVD Status LED(s) flashing.	The contactor is in the wrong state (SC200 or SC100 internal state does not match signal from contactor auxiliary switch).	Check the electrical and mechanical operation of the contactor and auxiliary switch. Check all wiring and connectors. See Connections on page 7 .
	<i>LVD Type</i> setting is incorrect.	Check <i>LVD Type</i> setting.
LVD contactor(s) not operating.	LVD settings incorrect.	Check LVD is enabled and set to correct values. See details in the System Controller Operation Handbook. Check that the LVD manual control is set to AUTO. See details in the System Controller Operation Handbook. Check that the contactor is correctly configured and mapped to the I/O board. See details in the System Controller Operation Handbook (SC200 only).
	Contactor is disconnected.	Check the control and dc power cables are connected. See details on page 7 .
MOV Fail Alarm active.	One or more MOVs have failed because of lightning strike(s) or ac transients.	Check the visual indicators on all the MOVs. If a visual indicator indicates a failed MOV, replace all the MOVs as soon as possible. See Monitoring and Replacing Transient Protective Devices on page 63 , on page 85 .
	One or more MOV cartridges not properly fitted.	Check that the MOV cartridges are properly inserted in the MOV cartridge holders.
	Faulty MOV Fail alarm wiring.	Check the MOV Fail alarm wiring.
All other SC200 or SC100 problems.		See Troubleshooting in the SC200 or SC100 Operation Handbook.

Replacing or Adding a Rectifier

Rectifiers can be replaced without switching off the dc power system and disconnecting the equipment it powers.



- To reduce the risk of electric shock and maintain optimum system cooling, always cover empty rectifier slots with blanking panels.
- To avoid electric shock do not place hands inside the rectifier shelf.
- Do not attempt to disassemble faulty rectifiers. Return them (in their original packaging) with a completed Equipment Incident Report on page [101](#).

Removing a Rectifier

Step 1 - Undo the rectifier retaining screw




This will release the rectifier from its rear connector.

Step 2 - Pull out the rectifier



- The rectifier may be hot, especially after prolonged operation. Use suitable gloves.



Step 3 - Replace rectifier or fit blank panel



Insert a replacement rectifier into the empty slot (see details in following section), or fit a blank panel.

Procedure complete

Installing a Replacement Rectifier

Step 1 - Remove rectifier blank panel (if fitted)




Step 2 - Align the rectifier with the guides



Step 3 - Push in the rectifier



- 1 Push in the rectifier until the retaining screw contacts the shelf.
- 2 Check the rectifier's rear connector is correctly aligned with the shelf connector or damage may occur.
- 3 Tighten the retaining screw to 1.5Nm (13.3 inch-pounds). This will locate the rectifier in its rear connector.
- 4 Check that the rectifier's Power On LED turns on (after the startup delay) and the alarm LEDs turn off.
 - The rectifier will automatically register with the system controller and download its operating parameters. No adjustments are required.*



Procedure complete

Replacing or Adding a Load MCB

Step 1 - Access MCBs



- 1 The load MCBs are located in the distribution space. See the diagram on page [2](#).

Step 2 - Remove existing MCB (if required)



- 1 Disconnect the load cable and the fuse fail detect wire from the MCB top terminal. Insulate the ends of both the cable and the wire.
- 2 Undo the bottom MCB terminal
- 3 Unclip the MCB from the DIN rail and remove the MCB.

Step 3 - Fit new MCB



- The dc distribution can use either Chint or Schneider circuit breakers. However, Chint and Schneider circuit breakers are not interchangeable. When replacing existing circuit breakers or fitting new ones, use the type that is already in use (see Spare Parts on page [66](#) for ordering details).*

- 1 Undo the bottom MCB terminal.
- 2 Insert the new MCB onto the tooth-comb bus and clip onto the DIN rail.
- 3 Tighten the bottom MCB terminal.

Step 4 - Fit a fuse fail detect wire



- 1 Place a spare fuse fail detect wire into the top terminal of the MCB.
- 2 Tighten the top MCB terminal.

Step 5 - Connect load cable (if required)



Follow the procedure on page [24](#), ensuring that the load cable size is sufficient for the MCB (see details on page [75](#)).

Procedure complete

Replacing a Load or Battery Fuse Link

Step 1 - Access the fuses



The load fuses are located in the distribution space. See the diagram on page [2](#).

Step 2 - Remove blown fuse link




- 1 Identify the blown fuse.
- 2 For battery fuses disconnect the fuse fail detect wires.
- 3 Remove the fuse link using the tool provided.

Step 3 - Fit new fuse link



- 1 Use the tool supplied to fit a new fuse link of the required rating.
- 2 For battery fuses only:
 - Use a striker type fuse link.
 - Remove the fuse fail detection board from the old fuse and fit to new fuse.
 - Re-connect the fuse fail detect wires.



- 1 Fuse link (striker type for battery fuses only)
- 2 Live cable
- 3 Fuse fail detection board (battery fuses only)

Procedure complete

Adding a Load Fuse

Step 1 - Access the fuses



- 1 The load fuses are located in the distribution space. See the diagram on page [2](#).

Step 2 - Fit new fuse base and link



- 1 Bolt the new fuse base to the live bus.
- 2 Tighten the bolt according to the Standard Torque Settings on page [67](#).

Step 3 - Fit a fuse fail detect wire



- 1 Place a spare fuse fail detect wire into the top terminal of the fuse.
- 2 Tighten the top terminal.

Step 4 - Connect load cable (if required)



Follow the procedure on page [24](#), ensuring that the load cable size is sufficient for the fuse (see details on page [75](#)).

Procedure complete

Replacing the System Controller

The SC200 or SC100 system controller can be replaced without switching off the dc power system and disconnecting the equipment it powers.

Before you start you will require:

- A PC/Laptop with *DCTools** connected to the system controller or (SC200 only) a web browser* connected to the system controller via an IP network.
 - *See *Communications Options in the System Controller Operation Handbook*.
- A replacement SC200 or SC100 system controller.
 - A new system controller is factory loaded with a 48V (nominal) default configuration file. *DCTools* (SC200 only) can be used to modify the configuration file already loaded in a system controller. However, a system controller configured for a particular nominal system voltage (48V or 24V) can only be converted to the other nominal system voltage by loading a new configuration file.
- A copy of the appropriate configuration file, either:
 - use the configuration file saved from the existing system controller, or
 - contact your Eaton dc power system supplier to obtain a master configuration file to suit the dc power system. This file will have to be customized for the site.

Step 1 - Backup the configuration file of the old SC200 or SC100 if possible



If the old system controller is still operational use *DCTools* to backup its configuration file.

□ See *Backup and Restore* on page [44](#).

Step 2 - Remove the system controller



- 1 Open the distribution space door to access the rear of the system controller.
- 2 Label, and then disconnect the cables from the rear connectors.
 - ☐ When the system controller stops communicating the rectifier output voltage will be unchanged for 2 minutes. After 2 minutes the rectifier output voltage will change to the Float Voltage and the rectifier yellow LEDs will flash.
- 3 Undo the four retaining screws.
- 4 Remove the SC200 or SC100.

Step 3 - Insert the new SC200 or SC100



- 1 Insert the SC200 or SC100 and tighten the retaining screws.
- 2 Connect the cables to the rear connectors.
 - ☐ The system controller will start. See Starting the SC200 or SC100 on page [45](#). Various alarms may appear because of incorrect configuration file settings. Press any key to silence the alarm.

Step 4 - Download the configuration file



- 1 Connect to the system controller with *DCTools*. See details on page [48](#) in the System Controller Operation Handbook.
- 2 If a copy of the old configuration file, or a master configuration file is available, then use *DCTools* to restore (download) it to the new system controller.
 - ☐ See *Backup and Restore* on page [44](#) in the System Controller Operation Handbook.
 - ☐ If you receive an error message about the MIB file version, please contact your Eaton dc product supplier for advice.
- 3 If a copy of the old configuration file, or a master configuration file is not available, then use the keypad or *DCTools* to change the configuration settings to the correct values (provided the system controller is set for the correct nominal system voltage).

Step 5 - Check the system controller operation



- 1 Map the I/O board (SC200 only):
 - In *DCTools* go to: *RXP*.
 - Copy the I/O board serial number(s) from the *RXP Devices* table to the *I/O Board to Serial Number Mapping* table to map an *IOB Number* to each I/O board (overwrite an existing serial number if required).
 - ☐ If multiple SiteSure-3G modules are connected use the *I/O board Identify* function to physically identify each module. See details in the System Controller Operation Handbook.
- 2 Check that the system controller has registered all rectifiers.
- 3 Check all control processes, alarms and current measurement(s).
- 4 Check the power system identification parameters and communications settings.
- 5 Change the configuration file as required to ensure that the system controller operates as intended.
- 6 Check the system controller time (SC200 only). See details in the System Controller Operation Handbook.

Step 6 - LVD Characterization Alarm



If LVD(s) are fitted the system controller may indicate an LVD Characterization alarm.

If there is no alarm, then no further action is required.

- 1 On the SC200 go to: Battery > LVDs > LVD x > Not Characterized > Edit, or on the SC100 go to: Menu > Configuration > LVD1/LVD2
- 2 If available, select *Characterize With IOB Values*. Press *Enter*. Repeat for other LVD(s) if fitted. No further action is required.
- 3 If *Characterize With IOB Values* is not available, the LVD(s) must be characterized. This will cause the LVD(s) contactor(s) to disconnect for a few seconds:
 - If a battery disconnect LVD is fitted, then the load equipment will continue to be powered by the rectifiers.
 - If a load disconnect LVD is fitted, then connect a temporary bridge cable from the rectifier bus to the load bus to power the low priority load equipment when the load LVD disconnects. See Replacing the Input/Output Board.
- 4 On the SC200 go to: Battery > LVDs > LVD x > Not Characterized > Edit, or on the SC100 go to: Menu > Configuration > LVD1/LVD2
 - Select *Characterize*. Press *Enter*.
 - The LVD contactor will disconnect and connect.
 - Repeat for other LVD(s) if fitted.
- 5 Remove the LVD bridge cable if fitted.

Procedure Complete

Return the faulty system controller with a completed Equipment Incident Report on page [101](#).

Replacing the Input/Output Board



- When the I/O board is removed any LVD fitted will disconnect:
 - If a battery disconnect LVD is fitted the battery will be disconnected when the I/O board is removed (the load equipment will continue to operate from the rectifiers).
 - If a load disconnect LVD is fitted then this LVD must be bridged so that the low priority loads are not disconnected when the I/O board is removed.

Before you start you will require:

- A PC/Laptop with *DCTools** connected to the system controller or (SC200 only) a web browser* connected to the system controller via an IP network.
 - *See *Communications Options in the System Controller Operation Handbook*.
- A replacement input/output board.
- An anti-static wrist strap to prevent damage to the static sensitive components on the input/output board.
- An LVD bridge cable if a load disconnect LVD is fitted.

Step 1 - Bridge load disconnect LVD(s) (if fitted)



Ignore this Step if there is no load disconnect LVD fitted.

- 1 Connect suitable cable(s) from the rectifier bus to the load bus to bridge the load disconnect LVD(s).
- 2 Tighten the bolts according to the standard torque settings on page [67](#).

Step 2 - Remove the I/O board



- 1** The I/O board is located on the back of the distribution space door. See the diagram on page [2](#).
- 2** Label then disconnect all I/O board cables.
 - Any LVDs fitted will disconnect. A Missing Hardware and other alarms will appear. Press any key to silence the alarm.*
- 3** Remove the I/O board.
- 4** Place the board in an anti-static bag and return for service. See Equipment Incident Report on page [101](#).

Step 3 - Fit the new I/O board



- 1** Reconnect all cables.
- 2** Check the I/O board Power On LED is on. If not see Troubleshooting on page [52](#).
 - Some alarms will clear. The Missing Hardware and LVD alarms (if LVDs are fitted) will still be present. A New Hardware alarm will appear because of the I/O board mapping change. Press any key to silence the alarm.*

Step 4 - Update I/O board mapping (SC200 only)



- 1** In DCTools go to: Configuration > RXP > I/O Board to Serial Number Mapping.
- 2** Copy the I/O board serial number from the RXP Devices table to the I/O Board to Serial Number Mapping table to map an IOB Number to the I/O board (overwrite existing serial number).
 - The alarms (except LVD alarms, if LVDs are fitted) will clear.*

Step 5 - Clear LVD Characterization alarm(s) (if required)



Ignore this Step if there is no LVD Characterization Error alarm.

- 1** On the SC200 go to: Battery > LVDs > LVD x > Not Characterized > Edit, or on the SC100 go to: Menu > Configuration > LVD1/LVD2
- 2** Select Use SC Values. Press Enter. No further action is required - go to (3).

If Use SC Values is not available then the LVD must be characterized. This will cause the LVD contactor(s) to disconnect for a few seconds.

- If LVD is a battery disconnect LVD then the load equipment will continue to be powered by the rectifiers.
- If LVD is a load disconnect LVD then the low priority load equipment will continue to be powered via the LVD bridge cable.
- On the SC200 go to: Battery > LVDs > LVD x > Not Characterized > Edit, or on the SC100 go to: Menu > Configuration > LVD1/LVD2

The LVD contactor will disconnect and connect. When the characterization is complete the LVD Characterization Error alarm will clear.

- 3** Repeat for other LVD(s) if fitted.

Step 6 - Remove the LVD bridge cable(s) (if fitted)**Ignore this Step if no LVD bridge cable was fitted.****Procedure complete**

Monitoring and Replacing Transient Protective Devices

For information on transient protection devices see Input Transient Protection on page [85](#).

Metal oxide varistors (MOVs) are the most widely used transient protective devices. MOVs are generally fitted in the main ac switchboard of the building for primary transient protection, and in the ac sub-switchboard or dc power system's ac distribution module for secondary transient protection.

Monitoring the MOVs

MOVs are fitted with alarm contacts and visual indicators. Connect these alarms to the system controller and from there extended to the building or network management system. If the MOVs are not monitored automatically, then regular visual inspections must be carried out.

Replacing the MOVs

MOVs must be functional at all times. In practice, it is impossible to predict when a MOV will fail. That depends entirely on the number and magnitude of the transients sustained.

For that reason we recommend the following, depending on how accessible the site is.

- **For easily accessible sites** – If a MOV has failed (as indicated by a MOV Fail alarm or the visual indicator), then replace all the MOVs as soon as possible.
- **For remote sites with difficult access** – Replace all the MOVs during scheduled maintenance visits, whether they have failed or not.



We strongly recommend inspecting the MOVs in the main ac switchboard at the same time and replacing them as appropriate.

If any MOV or other transient protection device has failed then the design of the primary and secondary transient protection systems, and the maintenance plan, at that site must be reviewed.

Battery Mid-point Monitoring (String Fail) Alarm (SC200 only)

Use the following procedure if a *String Fail* alarm is generated.

Step 1 - Identify the faulty battery string

- 1 Press any button on the SC200 to silence the alarm.
- 2 Connect to the SC200 using DCTools/Web. Go to *Batteries > Mid-point Monitoring*.
- 3 Click + to expand the *Mid-point Monitoring* table to identify which battery string has failed.

Step 2 - Check cell/monobloc voltages



- 1** Use a suitable voltmeter to measure the individual cell/monobloc voltages. Measure on the cable lugs and inter-connecting bars so that loose connections will also be detected.
- 2** The faulty or poorly connected cell/monobloc has the voltage with the greatest deviation from the average.

Step 3 - Check cell/monobloc terminals



- 1** Check the terminal connections of the cell/monobloc are correctly tightened and clean.
□ Refer to the battery manufacturer's instructions for correct terminal torque settings.
- 2** In DCTools/Web go to *Batteries > Mid-point Monitoring*. Click *Clear String Fail*.
- 3** If the alarm clears then the fault is fixed. No further action is required.

Step 4 - Service or replace faulty cell/monobloc (if required)



- 1** If the alarm is still present then follow the battery manufacturer's instructions on servicing or replacing the faulty cell/monobloc.
- 2** After the faulty cell/monobloc has been serviced or replaced clear the alarm (see Step 3).

Procedure complete

Battery Disposal and Recycling

Follow Environmental Protection Agency (EPA) guidelines or the equivalent local regulations to dispose of all batteries. Please remember that the owner is responsible and liable to ensure those EPA guidelines or equivalent local regulations are followed.

For assistance contact your local hazardous waste facility or Worldwide Support on page [103](#).

Equipment and Tools

Safety Equipment

Use approved safety equipment as required by local health and safety regulations including (but not restricted to):

- Safety glasses
- Safety gloves
- Safety footwear
- Appropriate handling equipment for batteries and other heavy items
- Appropriate platform(s) and access for working at height (if required)

Essential Tools

Standard electrical toolkit with insulated tools, plus:

- Cable crimping tool and crimp lugs suitable for all cable sizes and connectors used
- Torque wrench with pivot head and insulated handle
- Heatshrink tubing and heat gun
- Digital multimeter
- Insulation tester
- Non-static clothing

Recommended Tools

- Laptop with:
 - USB port (for use with SC200) or RS232 port (for use with SC100)
 - DCTools software (download from dcpower.eaton.com/downloads).
- Test load (to suit maximum output of dc power system)
- Labeling tool and labels
- Clamp-on ammeter

Spare Parts

Item	Description	Part Number
1	Rectifier See replacement procedure on page 56 .	48V, 2000W: Eaton APR48-ES 48V, 1800W: Eaton APR48-3G 24V, 1440W: Eaton APR24-3G
2	Rectifier blank panel (to cover un-used rectifier positions)	Eaton RMB1U-00
3	System controller See replacement procedure on page 59 .	Eaton SC100-00 or SC200-00
4	Input/Output Board. See replacement procedure on page 61 .	Eaton IOBGP-01
5	USB A/B cable for use with SC200 system controller	RadioShack 55010997, Jaycar WC7700, or equivalent.
6	RS232 DB9 F/F Null-modem cable - for use with SC100 system controller	RadioShack 55010600, Jaycar WC7513, or equivalent. (Cross-over connections: 5-5, 2-3, 3-2)
7	SiteSure-3G Input/Output Module (optional) (SC200 only)	Eaton IOBSS-00. See details on page 32 .
8	Dual temperature sensors (2m leads)	Eaton TS2-200
9	Battery Mid-point Monitoring connection kit for use with SC200 (for two battery strings)	Eaton MPTLOOM-3300 (2 x 3m sense wires), or Eaton MPTLOOM-7600 (1 x 7m, 1 x 6m sense wires)
10	Chint or Schneider circuit breakers	Contact Eaton

Standard Torque Settings

Use the following torque settings unless specific values are stated on the fastener or elsewhere. For battery terminals use the torque values specified by the battery manufacturer.

Thread Size ISO Coarse	Minimum - Maximum Torque
M2.5	0.3 - 0.4Nm (2.7 - 3.5 inch-pounds)
M3	0.5 - 0.6Nm (4.5 - 5.3 inch-pounds)
M4	1.1 - 1.3Nm (9.8 - 11.5 inch-pounds)
M5	2.3 - 2.7Nm (20.5 - 23.9 inch-pounds)
M6	3.9 - 4.5Nm (35 - 39 inch-pounds)
M8	9.5 - 11.1Nm (85 - 98 inch-pounds)
M10	18.7 - 21.9Nm (166 - 194 inch-pounds)
M12	32.8 - 38.4Nm (292 - 340 inch-pounds)
M16	81.5 - 95.1Nm (724 - 844 inch-pounds)

Notes:

- 1 Torque settings are for mild steel, brass and stainless steel.
- 2 Torque is based on 60% of yield stress of the material. Yield for the purposes of this chart is 240MPa.
- 3 Tolerance range is 60 - 70 % of yield.
- 4 When a bolt and nut is torqued use a spanner to prevent rotation.
- 5 Use hand tools when loosening and tightening stainless steel fasteners. Lubricate bolts before tightening to prevent them locking up.

System Input

Input Voltage <i>Refer to the rectifier specifications for range.</i>	220-240V (nominal L-N) 208V (nominal L-L)
Input Current (maximum) (per phase @ V = 175V)	Systems with integrated batteries: 1P+N+PE (220-240V nom.): 120A 2P+PE (208V nom.): 120A/ph 3P+N+PE (220-240V nom.): 48A/ph 3P+PE (208V nom.): 73A
	Systems without integrated batteries: 3P+N+PE (220-240V nom.): 168A/ph 3P+PE (208V nom.): 280A/ph
Frequency Range	45-66Hz
Earth Leakage Current (maximum)	1.3mA per rectifier

System Output

Output Voltage (nominal)	24V / 48V (dependent on rectifier model)
Output Power (maximum)	Systems with integrated batteries: 24V: APR24-3G rectifiers: 14.4kW* 48V: APR48-3G rectifiers: 18kW* APR48-ES rectifiers: 20kW*
	Systems without integrated batteries: 24V: APR24-3G rectifiers: 57.6kW* 48V: APR48-3G rectifiers: 72kW* APR48-ES rectifiers: 80kW*
Output Voltage Range	21.5 - 32V / 43 - 57.5V

* subject to the maximum load currents as follows

Load Currents

Module Type Number	Description	Load Current (Maximum)
DCDIX1618-010	DV2-3G Distribution with Load MCBs - 16 x 18mm, Battery fuses - 2 x DIN02, Battery Shunt x 1. 600A capacity.	Load: 600A Battery: 500A
DCDIX2418-101	DV2-3G Distribution with Load MCBs - 12 x 18mm priority and 12 x 18mm non-priority, Load LVD x 1. 400A + 400A capacity.	2*400A
DCMIX2418-000	DV2-3G Distribution with Load MCBs - 24 x 18mm. 1000A capacity.	1000A
DCMIX1627-000	DV2-3G Distribution with Load MCBs - 16 x 27mm. 1000A capacity.	1000A
DCFIX1000-000	DV2-3G Distribution with Load fuses - 10 x DIN00. 1200A capacity.	1200A

DCFIX0602-000	DV2-3G Distribution with Load fuses - 6 x DIN02. 1500A capacity.	1500A
DCFIX0403-000	DV2-3G Distribution with Load fuses - 4 x DIN03. 1500A capacity.	1500A
DCFIX0404-000	DV2-3G Distribution with Load fuses - 4 x DIN04. 2400A capacity.	2400A
DCF14TPS-00	DV2-3G Distribution with Load fuses - 14 x TPS. 600A capacity.	600A
LVDIX0601-211	DV2-3G LVD with Single 600A Contactor, Battery fuses - DIN03 x 2, Battery Current Shunt.	Load: 330A Battery: 450A
LVDIX0602-211	DV2-3G LVD with Dual 600A Contactors, Battery fuses - DIN03 x 2, Battery Current Shunt.	Load: 2*300A Battery: 2*400A
LVDIX0602-011	DV2-3G LVD with Dual 600A Contactors, CS04-A11 Current Shunt.	Load: 2*400A Battery: 2*475A
LVDIX1001-000	DV2-3G LVD with Single 1000A Contactor.	800A
LVDIX1002-000	DV2-3G LVD with Dual 1000A Contactors.	2*800A
LVDIX2001-000	DV2-3G LVD with Single 2000A Contactor.	1600A
LVDIX2002-000	DV2-3G LVD with Dual 2000A Contactors.	2*1600A
DCFIX0203-001	DV2-3G Distribution with fuses - 2 x DIN03, 945A capacity.	2*472.5A
DCFIX0204-001	DV2-3G Distribution with fuses - 2 x DIN04, 1875A capacity.	2*937.5A
DCFIX0204A-010	DV2-3G Distribution with fuses - 2 x EFEN 04A, 1 for Load, 1 for Battery with CS04-A11, Feed from -V00	Load: 1200A Battery: 1200A
DCFIX0204A-011	DV2-3G Distribution with fuses - 2 x EFEN 04A For Loads, Feed from -HL0	2*1200A
DV2-A10B-400	+E, RACKIX200, DOORIX8 (DCDIR1, No LVD, ACDIR410), RM10(x1), BTRAYIX(x4)	Max current per DCD and total load current: 337.5A
DV2-A10B-401	+E, RACKIX200, DOORIX8 (DCDIR1, LVDIX401, ACDIR410), RM10(x1), BTRAYIX(x4)	Max current per DCD and total load current: 337.5A
DV2-A10B-402	+E, RACKIX200, DOORIX8 (DCDIR1, LVDIX402, ACDIR410), RM10(x1), BTRAYIX(x4)	Max current per DCD and total load current: 337.5A
DV2-A20-4000	+E, APR48-3G or APR48-ES, 3P+N+PE Star, RACKIX200, DOORIX34, (SC200, ACDIX425-10000), 1U, RM10(x2), 2U	750A or 832A
DV2-A20-3000	+E, APR48-3G or APR48-ES, 3P+PE Delta, RACKIX200, DOORIX34, (SC200, ACDIX425-10000), 1U, RM10(x2), 2U	750A or 832A
DV2-A40-4000	+E, APR48-3G or APR48-ES, 3P+N+PE Star, RACKIX200, DOORIX28, (SC200, ACDIX425-10000), 1U, RM10(x4), 2U	1500A or 1664A

DV2-A40-3000	+E, APR48-3G or APR48-ES,3P+PE Delta, RACKIX200, DOORIX28,(SC200,ACDIX425-10000),1U,RM1 0(x4),2U	1500A or 1664A
DV2-A60-4000	+E, APR48-3G or APR48-ES, 3P+N+PE Star, RACKIX200, DOORIX22,(SC200,ACDJX425-10000),1U,RM1 0(x6),2U	2250A or 2496A
DV2-C12-4000	+E,CR48-3G, 3P+N+PE Star, RACKIX200, DOORIX28,(SC200,ACDJX425-10000),1U,3U,R MC4(x3),2U	1440A
DV2-C12-3000	+E,CR48-3G, 3P+PE Delta, RACKIX200, DOORIX28,(SC200,ACDJX440-10000),1U,3U,R MC4(x3),2U	1440A
DV2-C16-4000	+E,CR48-3G, 3P+N+PE Star, RACKIX200, DOORIX28,(SC200,ACDJX425-10000),1U,RMC 4(x4),2U	1920A
DV2-C16-3000	+E,CR48-3G, 3P+PE Delta, RACKIX200, DOORIX28,(SC200,ACDJX440-10000),1U,RMC 4(x4),2U	1920A
DV2-C20-4000	+E,CR48-3G, 3P+N+PE Star, RACKIX200, DOORIX22,(SC200,ACDJX440-10000),1U,3U,R MC4(x5),2U	2400A
DV2-C24-4000	+E,CR48-3G, 3P+N+PE Star, RACKIX200, DOORIX22,(SC200,ACDJX440-10000),1U,RMC 4(x6),2U	2880A

Rectifiers

Operating Ranges	
APR24-3G/APR48-3G:	
	Rated: 175 – 275V <i>Full output up to 50°C [122°F]</i>
	Extended: 90 – 300V <i>Reduced output power below 175V</i>
APR48-ES:	
	Rated: 185 – 275V <i>Full output up to 50°C [122°F]</i>
	Extended: 90 – 300V <i>Reduced output power below 185V</i>
Input Current (maximum) 20°C [68°F]	APR24-3G: 9.5A @ 175V ac APR48-3G: 12A @ 175V ac APR48-ES: 12A @ 185V ac
Rated Output Power	APR24-3G: 1440W APR48-3G: 1800W APR48-ES: 2000W
Rated Output Current	APR24-3G: 50A @ 28.8V APR48-3G: 37.5A @ 48V APR48-ES: 41.7A @ 48V
Preset Voltage	APR24-3G: 27V \pm 0.1V APR48-3G: 54.5V \pm 0.1V APR48-ES: 54.5V \pm 0.1V
Rectifier Input Fuses (internal)	16A, 250V

Environment

Ambient Temperature Range (<i>operating</i>)	-5°C to 50°C [23°F to 122°F]
Relative Humidity (<i>operating and storage</i>)	<95% (non condensing)

Dimensions H, W, D

Cabinets	43U racks: 2000mm [78.7"], 600mm [23.6"], 600mm [23.6"]
Rectifiers	3U: 133mm [5.25"], 42mm [1.65"], 266mm [10.45"] overall

Weight

Excluding rectifiers and batteries	Systems with integrated batteries: 85kg [188 lb] typical Systems without integrated batteries: 120kg [264 lb] typical Additional battery rack option: 85kg [188 lb] typical
Rectifier module	1.7kg [3.7 lb]

Digital Outputs/Alarm Relays (IOBGP)

Number of Digital Outputs/Relays	6 (one also used for Monitor OK alarm)*
Contact Arrangement	One changeover contact per relay
Contact Rating	0.1A @ 60V dc maximum
Connectors	Screwless terminal blocks
Wire Size	0.5 - 2.0mm ² [20 - 14 AWG]
Maximum Cable Length	20m (65 feet)
Isolation	Relay connections are isolated to 500V dc from all other circuitry, earth and system common.

* Digital Output 6 is also used as the Monitor Fail alarm relay. It will de-energize if the I/O board loses power or loses communication with the SC200 or SC100.

Digital Inputs (IOBGP)

Number of Digital Inputs	6
Connectors	Screwless terminal blocks
Wire Size	0.5 - 2.0mm ² [20 - 14 AWG]
Maximum Cable Length	20m (65 feet)
Input Types	Voltage-free switch or relay contacts only
Input Range	Live Bus to Live Bus + 5V
Input Common	Same bus as used for current shunts (Live bus is standard)
Input Protection	Protected against damage from short circuit to live or common bus

Temperature Sense Inputs (IOBGP)

Number of Temperature Sense Inputs	2 - One only connected as standard. Second input available (requires additional temperature sensor).
Range	2.53V to 3.43V (-20 to +70°C [-4 to +158°F])
Resolution	< 0.01V (< 1°C [1.8°F])
Accuracy	±1°C [1.8°F] at 25°C [77°F], ±2°C [3.6°F] over rated temperature range
Maximum Cable Length	20m (65 feet)
Connector	RJ45

Current Sense Inputs (IOBGP)

Number of Current Sense Inputs	3 (one used for internal current shunt)
Range	-50 to +50mV
Resolution	<50µV
Accuracy	±0.5% at 25°C [77°F], ±1% over rated temperature range
Maximum Cable Length	10m (32 feet)
Connector	RJ45

Battery Mid-point Monitoring (SC200 only)

Number of Strings	Standard: 4 Maximum: 24 (with additional IOBGP-01 I/O boards)
Range	-35V to +35V
Resolution	<30mV
Accuracy	±0.5% at 25°C [77°F], ±1% over rated temperature range
Maximum Cable Length	20m (65 feet)

Low Voltage Disconnect (IOBGP)

Number of contactor connections	2 per IOBGP I/O board
Number of LVD channels	SC100 systems: 2, SC200 systems: 16
Contactor Type	Normally Open (NO) or Normally Closed (NC)*, with or without auxiliary contacts. * For NC contactor operation the SC100 and IOBGP must be powered from the battery side of the LVD.
Contactor Coil Voltage (nominal)	With auxiliary contacts: 12V, 24V or 48V Without auxiliary contacts: Equal to nominal system voltage
Maximum Hold-in Current	1.2A (per contactor)
Maximum Cable Length	3m (10 feet)
Connector	MTA156 (4-way)

Communications

USB (SC200 only)	Version: 1.1 (12Mbits/s) Connector: USB B (female)
RS232	Interface: RS232 (DTE) Connector: DB9M
Ethernet (SC200 only)	Interface: 10baseT Connector: RJ45 Protocols: TCP/IP, SNMP, S3P over IP, http (Web), https (secure Web), SNTP, Modbus-TCP, Serial Server MAC Address: See details in the System Controller Operation Handbook.
	Web browser: Microsoft Internet Explorer 8 or later (IE6 is compatible but with reduced performance), Mozilla Firefox 3.0 or later.
External modem options	Type: PSTN or GSM Operation: Dial in/Dial out on alarm*

* Can operate as a backup for Ethernet communications (SC200 only).

Cable Ratings**18 mm DIN rail MCB's**

Eaton Part Number*	Chint NB1 Series	Max Load Current 80% of Current Rating	Minimum cable size
307-900600-61	Chint, NB1-63 UL Series, 6A, Curve	4.8A	1mm ² / 16AWG
307-901000-61	Chint, NB1-63 UL Series, 10A, Curve	8A	1.25mm ² / 16AWG
307-901600-61	Chint, NB1-63 UL Series, 16A, Curve	12.8A	2.5mm ² / 12AWG
307-902000-61	Chint, NB1-63 UL Series, 20A, Curve	16A	4mm ² / 10AWG
307-902500-61	Chint, NB1-63 UL Series, 25A, Curve	20A	4mm ² / 10AWG
307-903200-61	Chint, NB1-63 UL Series, 32A, Curve	25.6A	6mm ² / 8AWG
307-904000-61	Chint, NB1-63 UL Series, 40A, Curve	32A	10mm ² / 6AWG
307-905000-61	Chint, NB1-63 UL Series, 50A, Curve	40A	16mm ² / 4AWG
307-906300-61	Chint, NB1-63 UL Series, 63A, Curve	50.4A	16mm ² / 4AWG

27 mm DIN rail MCB's

Eaton Part Number*	Chint DZ158-125 Series	Max Load Current 80% of Current Rating	Minimum cable size
307-908019-61	Chint, DZ158-125 Series, 80A, Curve	64A	25mm ² / 2AWG
307-910019-61	Chint, DZ158-125 Series, 100A, Curve	80A	35mm ² / 1AWG
307-912519-61	Chint, DZ158-125 Series, 125A, Curve	100A	50mm ² / 0AWG

* or local equivalent. Please contact your local Eaton sales office.

DIN Fuse Links

Eaton Part Number	DIN Fuses	Max Load Current 75% of Current Rating	Minimum cable size
305-910034-00	DIN00 Fuse link, 100A	75A	35mm ² / 1AWG
305-912534-00	DIN00 Fuse link, 125A	93A	50mm ² / 0AWG
305-916034-00	DIN00 Fuse link, 160A	120A	70mm ² / 000AWG
305-920034-02	DIN02 Fuse link, 200A	150A	120mm ² / 250KCMIL
305-925034-02	DIN02 Fuse link, 250A	187A	150mm ² / 300KCMIL
305-931534-02	DIN02 Fuse link, 315A	236A	240mm ² / 500KCMIL
305-940034-02	DIN02 Fuse link, 400A	300A	300mm ² / 600KCMIL
305-940034-03	DIN03 Fuse link, 400A	300A	300mm ² / 600KCMIL
305-950034-03	DIN03 Fuse link, 500A	375A	2*150mm ² / 2*300KCMIL
305-963034-03	DIN03 Fuse link, 630A	472A	2*240mm ² / 2*500KCMIL
305-980034-04	DIN04 Fuse link, 800A	600A	2*300mm ² / 2*600KCMIL
305-910034-04	DIN04 Fuse link, 1000A	750A	4*150mm ² / 4*300KCMIL
305-912534-04	DIN04 Fuse link, 1250A	937A	4*240mm ² / 4*500KCMIL
305-916034-05	DIN04A Fuse link, 1600A	1200A	4*300mm ² / 4*600KCMIL
305-916037-00	EFEN Fuse, NH-SI 4A 1600A, P/N 35097.0110	1200A	4*300mm ² / 4*600KCMIL

SC200 Menu




At each menu screen press *Enter* to access the associated configuration menu screen(s).

 These menus have multiple configuration menu screens. See details in the System Controller Operation Handbook.

SC100 Menu


The following diagram shows the Status Screens and main navigation.

□ See *Analog System Values* for details of the values displayed.




Connector Pin-outs**System Controller Connector Pin-outs**

Connector	Type	Purpose	Pin	Description
XS1	DB9M	RS232 Serial Interface	1	-
			2	RD (Receive Data)
			3	TD (Transmit Data)
			4	DTR (Data Terminal Ready)
			5	Common (Ground)
			6	-
			7	RTS (Request to Send)
			8	-
			9	-
XS31 (SC200 only)	RJ45	Ethernet Interface	1	Rx
			2	Rx
			3	Tx
			4	-
			5	-
			6	Tx
			7	-
			8	-
YS11	RJ45	RXP System Communications	1	+24/48V (System bus voltage)
			2	+24/48V (System bus voltage)
			3	-
			4	RS485-A
			5	RS485-B
			6	-
			7	0V
			8	0V
USB (SC200 only)	USB B	USB Serial Interface	1	VCC (+5 V dc)
			2	Data -
			3	Data +
			4	Ground



RS232 D9M and RJ45 connector pin-outs



RJ45 plug pin-outs

I/O Board (IOBGP-00, -01) Connector Pin-outs

See input and output specifications on page [69](#).


Connector	Type	Purpose	Pin	Description
XH4	MTA 156	LVD 1 Interface	1	Coil -
			2	Coil +
			3	LVD 1 auxiliary switch
			4	Auxiliary switch common
XH5	MTA 156	LVD 2 Interface	1	Coil -
			2	Coil +
			3	LVD 2 auxiliary switch
			4	Auxiliary switch common
XH6	RJ45	Current Sense Inputs	1	Current Input 1 Common
			2	Current Input 1
			3	+12V out
			4	Current Input 2 Common
			5	Current Input 2
			6	0V out
			7	Current Input 3 Common
			8	Current Input 3
XH7	RJ45	Temperature Sense Inputs	1	-
			2	-
			3	-
			4	Temp Sense 1+
			5	Temp Sense 1-
			6	-
			7	Temp Sense 2+
			8	Temp Sense 2-

Connector	Type	Purpose	Pin	Description
XH8	MTA 156	LVD Power	1	Bus live
			2	Common
XH9	MTA 156	Bus Voltage Sense Input	1	Controller reference (Live)
			2	Controller sense (Com)
XH12A	MTA 156	Battery Mid-point Monitoring sense inputs (SC200 only)	1	String 1 Mid-point
			2	String 2 Mid-point
			3	String 3 Mid-point
			4	String 4 Mid-point
XH15A		Digital inputs D1-D3	1	D1 input
			2	0V
			3	D2 input
			4	0V
			5	D3 input
			6	0V
XH15B		Digital inputs D4-D6	1	D4 input
			2	0V
			3	D5 input
			4	0V
			5	D6 input
			6	0V
XH16/XH17		Digital relay outputs 1-2	1	Relay 1 normally closed (NC)
			2	Relay 1 normally open (NO)
			3	Relay 1 Common (COM)
			4	Relay 2 normally closed (NC)
			5	Relay 2 normally open (NO)
			6	Relay 2 Common (COM)
XH18/XH19		Digital relay outputs 3-4	1	Relay 3 normally closed (NC)
			2	Relay 3 normally open (NO)
			3	Relay 3 Common (COM)
			4	Relay 4 normally closed (NC)
			5	Relay 4 normally open (NO)
			6	Relay 4 Common (COM)


Connector	Type	Purpose	Pin	Description
XH20/XH21		Digital relay outputs 5-6*	1	Relay 5 normally closed (NC)
			2	Relay 5 normally open (NO)
			3	Relay 5 Common (COM)
			4	Relay 6 normally closed (NC)
			5	Relay 6 normally open (NO)
			6	Relay 6 Common (COM)
YH3	RJ45	DC power system digital inputs	1	Load Fuse Fail
			2	Battery Fuse Fail
			3	+12V out
			4	AC Distribution Fan Fail
			5	AC Distribution MOV Fail
			6	0V out (system live - protected)
			7	-
			8	System common - protected
YH11	RJ45	RXP System Communications	1	+24/48V (System bus voltage)
			2	+24/48V (System bus voltage)
			3	-
			4	RS485-A
			5	RS485-B
			6	-
			7	0V
			8	0V



* Digital Output 6 is also used as the Monitor Fail alarm relay. It will de-energize if the I/O board loses power or loses communication with the SC200 or SC100.



RJ45 connector pin-outs




RJ45 plug pin-outs

System Components

External Current Sensors

CS04-A11 current sensor

Current rating:	> 500A
Mounting:	Screws (supplied) to the LIVE bus
Output signal:	60mV at maximum rated current
Communication cable:	8m (26') RJ45 (supplied)
Extension PCB:	For measurement on very large busbars
Busbar material:	Copper or Aluminum



For full information on installing the CS04-A11 Current Sensors see Application Note AN0046.

 To receive application notes see Worldwide Support on page [103](#).

Transient Protection

To prevent damage to Eaton Data-Voice-Video 3G Power Solutions from lightning and transient over-voltages, structural lightning protection and transient protection must be installed at each site.

Transient protection will also protect against other sources of transients, such as:

- Circuit or grid switching by the power company
- Electrical switching of large inductive loads (such as motors, transformers, and electrical drives) or capacitive loads (such as power factor correction) or manufacturing equipment.

Use a suitably qualified consultant to develop a transient protection plan (compliant with IEC 61643-12) for the equipment to be installed at the site. The transient protection plan and associated installation must:

- 1 Capture the lightning strike at a known and preferred point outside the building
- 2 Conduct the main lightning energy safely to earth
- 3 Dissipate the lightning energy into a low impedance earthing system
- 4 Eliminate earth potential differences inside the building
- 5 Protect the ac supply using a coordinated transient voltage surge suppression plan, that includes:
 - Primary surge protection
 - Secondary surge protection
 - Primary / secondary surge decoupling coils
 - Secondary / tertiary surge decoupling coils
- 6 Protect the data and control lines using a coordinated transient voltage surge suppression plan

Earthing (Grounding)

The most important aspect of any power system installation at a site is the integrity of the earthing systems. Effective earthing will significantly increase site protection. Most sites have a number of earthing systems such as:

- AC Power earth
- DC Power earth
- Tower / building lightning protection earth

For optimum protection, all earths must be brought together at one "star" point. Otherwise, surge currents can flow within the system creating large voltages. These can cause damage to equipment that does not normally require surge protection, such as rectifier outputs and communications interfaces.

If there is a tower on the site then use the tower earth as the "star" point. This is because it conducts the majority of the surge to earth, especially if the site is lightning-prone. For other sites, a 'direct-lightning' earth will not be available therefore a structural or power system earth will be used. In multi-floor buildings, always try to use structural earths if the common earth point cannot be found at ground level. For basements / single floor buildings, the ac supply earth is usually the most appropriate.

Primary Transient Protection


Primary transient protection must be considered at all sites. Eaton recommends primary transient protection on the incoming ac supply either at the main ac switchboard or sub-switchboard.

In the absence of sufficient information, primary transient protective devices with a minimum repeat strike rating of 100kA (8/20 μ s wave shape) are recommended.

In addition, primary transient protection must be coordinated with downstream secondary transient protection via suitably rated surge decoupling coils. These should have been specified as part of the transient protection plan for the site. If no surge decoupling coils were specified, then air-core 15 μ H surge decoupling coils are suitable.

Installation

Install the transient protection according to the following diagram.



① Supply transformer	⑦ Primary/secondary surge decoupling coils (4, refer to text for rating)	⑪ Spark gap (neutral-earth)
② Building entrance	⑧ AC sub-switchboard or DV2-3G dc power system	⑫ Switchboard earth/ground busbar
③ Main switchboard	⑨ Secondary transient protection	⑬ Secondary/Tertiary surge decoupling coils (4 x 11 μ H minimum)
④ Fuses	⑩ MOVs (3, phase-neutral, refer to text for rating)	⑭ Access Power Rectifiers
⑤ Primary transient protection (refer to text for rating)		
⑥ Building earth/ground busbar		

Transient protective devices are fitted with alarm contacts and visual indicators. Monitor the status of all externally installed transient protective devices. Either:

- Regularly inspect the visual indicators
- Connect the alarm contacts to the MOV Fail termination on the I/O board (preferred option) or to the building management system. See the Connections diagram on page [7](#) for location of MOV Fail termination (YH3) and connector pin-outs on page [80](#).

 *The alarm signal lines of the external transient protective devices must be isolated from the ac supply (by voltage-free relay contacts) before connecting these signal lines to the DV2-3G dc power system.*

Secondary Transient Protection

Secondary transient protection (downstream from the primary transient protection) must be present at all sites to protect the dc power system from transients.

Data-Voice-Video 3G Power Solutions are factory-fitted with secondary transient protection. This will protect the power system from a limited number of repeated 15kA transients (8/20 μ s wave shape).

Factory-fitted secondary transient protection consists of:

- Phase-to-neutral metal oxide varistors (MOVs) with a voltage rating of 440V, capable of withstanding temporary over-voltages
- A neutral-to-earth spark gap (gas discharge tube)
- Surge decoupling coils

If secondary transient protection is not fitted inside the Data-Voice-Video 3G Power Solutions, then external secondary transient protection must be installed in the ac switchboard that supplies the dc power system.

Carefully consider the residual voltage seen by the dc power system (maximum 6kV) and the decoupling between the transient protection system and the dc power system. Transients must be limited to less than 2kA.

Tertiary Transient Protection

Eaton rectifiers are fitted with 6kV/3kA transient protection. This is designed to protect the rectifiers from voltage spikes generated during operation of the upstream transient protection system. Do not install rectifiers without adequate upstream surge protection.

Commissioning

 Complete the tasks in this appendix only if a formal commissioning test is required.

Before starting these Commissioning tasks:

- Complete all the Installation tasks (see details)
- Complete all the Start-Up tasks (see details on page [38](#))
- Save a copy of the configuration file.

Complete the Commissioning tasks in the following order:

 During the testing, note any changes to the configuration file that are incorrect.

Task	Description	Reference
1	Analog Inputs	See details on page 90
2	System Controls	See details on page 92
3	System Alarms	See details on page 95
4	Digital Inputs	See details on page 98
5	Digital Outputs (Relays)	See details on page 99

Analog Inputs

Equipment required:

- Digital Voltmeter
- DC Load bank
- DC Current Clamp meter
- Trim pot adjustment tool
- Thermometer

Test	Test procedure	Adjustment
DC Voltage	<ul style="list-style-type: none"> • Measure the dc voltage across the dc bus. • Ensure the bus voltage on the SC200 or SC100 display and in DCTools is within specifications. 	None
Battery Current (High current test) Note 1	<ul style="list-style-type: none"> • Conduct the load test and turn off the rectifiers. • Measure the load current with a dc clamp meter. • Ensure the current displayed on the SC200 or SC100 and in DCTools is within specification. • Ensure the current is the correct polarity. 	Adjust the gain setting on the current sensor by moving the trim pot. Adjust the gain setting in the SC200 or SC100
Load Current (High current test) Note 2	<ul style="list-style-type: none"> • Connect a load bank to the dc load connection • Apply a high load to the system • Measure the load current with a dc clamp meter • Ensure the load current displayed on the SC200 or SC100 and in DCTools is within specification. • Ensure the current is the correct polarity. 	Adjust the gain setting on the current sensor by moving the trim pot. Adjust the gain setting in DCTools.
Total System Current (High current test)	<ul style="list-style-type: none"> • Repeat the load test. • Ensure the system current displayed on the SC200 or SC100 and in DCTools is within specification. 	None
Load Current (No current test)	<ul style="list-style-type: none"> • Disconnect the load bank from the system. • Ensure the load current displayed on the SC200 or SC100 and in DCTools is 0 amps. 	Adjust the current offset setting of the SC200 or SC100.
Battery Current (No current test)	<ul style="list-style-type: none"> • Disconnect the load bank from the system. • Ensure the battery current displayed on the SC200 or SC100 and in DCTools is 0 amps. 	Adjust the current offset setting of the SC200 or SC100.
Total System Current (No current test)	<ul style="list-style-type: none"> • Disconnect the load bank from the system. • Ensure the total system current displayed on the SC200 or SC100 and in DCTools is 0 amps. 	None
Temperature	<ul style="list-style-type: none"> • With thermometer, measure the temperature at the power system temperature sensor. • Ensure the temperature input displayed on the SC200 or SC100 and in DCTools is within specification. • Test each temperature input. 	Some temperature sensors have an adjustable trim pot.
User assigned Analog Inputs Note 3	<ul style="list-style-type: none"> • Test the accuracy and alarm mapping for all analog inputs. • Check the name, severity and alarm thresholds are correct. 	See Note 3.

Notes

- 1 When the rectifiers are turned off, the battery current will supply all the current to the load. At this time the battery current will equal the load current. This test assumes there is a current sensor on the dc Load Bus. If batteries are not installed on the system, connect the load bank to the battery bus. If the battery current is determined by a summation, conduct the load current test before the battery current test.
- 2 The test should be done at the maximum expected system load current. This test assumes there is a current sensor on the dc load bus.
- 3 As the analog inputs can be configured for many different types of analog signal, tests have not been detailed on this test sheet. User assigned analog inputs are not available on all systems.

System Controls

Equipment Required:

- DC Load bank

Test	Test procedure	Adjustment
Voltage Control Note 1	<ul style="list-style-type: none"> • Apply a load to the power system. • With <i>DCTools</i>, ensure the bus voltage matches the <i>Target Voltage</i> as shown on the Voltage Control Summary of <i>DCTools</i>. 	None
Temperature Compensation Note 2	<ul style="list-style-type: none"> • Heat the battery temperature sensor. • Ensure the system voltage changes in accordance with the configured slope. 	None
Equalize	<ul style="list-style-type: none"> • Set the <i>Equalize Duration</i> to 1 minute. • Start an <i>Equalize</i>. • Ensure the system voltage increases to the <i>Equalize Voltage</i>. • Ensure the SC200 or SC100 indicates an <i>Equalize</i> has started. • Ensure the <i>Equalize</i> stops after the 1 minute duration. • Return the <i>Equalize</i> duration to the original setting. 	None
Fast Charge Note 3	<ul style="list-style-type: none"> • Set the <i>Fast Charge Max Duration</i> to 1 minute. • Set the <i>Fast Charge Voltage Threshold</i> to a value approximately 1V below the system float voltage. • Connect load to the system. • Turn off the ac to the system. • Allow the system voltage to fall below the <i>Fast Charge Voltage Threshold</i>. • Turn on the ac. • Ensure the system performs a <i>Fast Charge</i>. • Ensure the SC200 or SC100 indicates a <i>Fast Charge</i> has started. • Ensure the <i>Fast Charge Voltage</i> is correct. • Ensure the <i>Fast Charge</i> stops after 1 minute. • Return the <i>Fast Charge</i> settings to the original values. 	None
Generator Control Option (SC200 only) Note 4	<ul style="list-style-type: none"> • Set the <i>Voltage Threshold</i> to a value approximately 1V below the system float voltage. • Connect load to the system. • Turn off the ac to the system. • Allow the system voltage to fall below the <i>Voltage Threshold</i>. • Ensure the system performs a <i>Fast Charge</i>. • Ensure the SC200 indicates a <i>Generator Enable</i>. • Ensure the <i>Generator Enable</i> digital output activates. • Turn on the ac. • Ensure the <i>Generator Enable</i> stops after 1 minute. • Return the settings to the original values. 	None
Battery Current Limit Note 5	<ul style="list-style-type: none"> • Reduce the <i>Battery Current Limit</i> setting to 5%. • Connect load to the system. • Turn off the ac to the system. • Allow the battery to discharge for a period. • Turn on the ac. • Monitor the battery current to ensure the <i>Battery Current Limit</i> control process is operating. 	None

Test	Test procedure	Adjustment
Current Share Note 6	<ul style="list-style-type: none"> View the individual rectifier currents with the SC200 or SC100 or DCTools. Ensure the currents are all at 0 amps. Connect load to the system. Ensure that all rectifiers share the load evenly and any variation is within specification. 	None
Battery Test	<ul style="list-style-type: none"> Set the <i>Battery Test Interval</i> to 0 days. Set the <i>Battery Test Duration</i> to 30 minutes Set the <i>Battery Test Termination Voltage</i> to a value approximately 2 volts below the float voltage. Connect load to the system. Start the <i>Battery Test</i>. Ensure the SC200 or SC100 indicates that a <i>Battery Test</i> has started. Wait until the system voltage reduces below the <i>Termination Voltage</i>. Confirm the <i>Battery Test</i> fails. Ensure the <i>Battery Test Fail</i> alarm is displayed on the SC200 or SC100. Ensure the <i>Battery Test</i> stops and the system voltage returns to the float voltage setting. Clear the <i>Battery Test Fail</i> alarm in DCTools. Set the <i>Battery Test Duration</i> to 1 minute. Set the <i>Battery Test Termination Voltage</i> to a value approximately 10 volts below the float voltage. Connect load to the system. Start the <i>Battery Test</i>. Ensure the SC200 or SC100 indicates that a <i>Battery Test</i> has started. Wait for the <i>Battery Test Duration</i> time to expire. Confirm the <i>Battery Test</i> passes. Ensure the <i>Battery Test</i> stops and the system voltage returns to the float voltage setting. Reset the <i>Battery Test</i> settings to the original values. 	None
Low Voltage Disconnect – Manual Operation Note 7	<ul style="list-style-type: none"> Set the LVD manual control to CONNECT. Ensure the LVD contactor is connected. Ensure the SC200 or SC100 displays an <i>LVD Manual</i> alarm. Ensure the I/O board LVD LED is on. Set the LVD manual control to AUTO. Ensure the SC200 or SC100 shows no LVD alarms. Ensure the I/O board LVD LED is on. Set the LVD manual control to DISCONNECT. Ensure the LVD contactor disconnects. Ensure the SC200 or SC100 displays an LVD Manual alarm. Ensure the I/O board LVD LED is off. Set the LVD manual control to AUTO. Ensure the LVD connects. Ensure the SC200 or SC100 shows no LVD alarms. Ensure the I/O board LVD LED is on. 	None

Test	Test procedure	Adjustment
Low Voltage Disconnect - Automatic Operation Note 7	<ul style="list-style-type: none"> Check the LVD contactor is connected. Increase the <i>LVD Disconnect Voltage Threshold</i>. Reduce the system voltage below the <i>LVD Disconnect Voltage Threshold</i>. Wait for the configured <i>Recognition Period</i>. Ensure the LVD disconnects. Ensure the SC200 or SC100 displays an <i>LVD Disconnected</i> alarm Ensure the I/O board LVD LED is off. Increase the system voltage above the configured <i>Reconnect Voltage</i>. Wait for the configured <i>Recognition Period</i>. Ensure the LVD connects. Ensure the SC200 or SC100 shows no LVD alarms. Ensure the I/O board LVD LED is on. 	None
Low Voltage Disconnect - Alarms Note 7	<ul style="list-style-type: none"> Disconnect each LVD control cable from the I/O board. Ensure the SC200 or SC100 displays an <i>LVD Fail</i> alarm. Ensure the I/O board LVD LED is flashing. Reconnect the cables. Ensure the LVD connects. Ensure the SC200 or SC100 shows no LVD alarms. Ensure the I/O board LVD LED is on. 	None

Notes

- 1 AVC must be enabled. Allow up to 1 minute for the system to stabilize after load or voltage changes.
- 2 Breathing on the sensor can increase the temperature.
- 3 Battery Current Limit control process may have to be turned off to allow the Fast Charge voltage to reach its value within the 1 minute test duration.
- 4 For details see Generator Control Option in the System Controller Operation Handbook.
- 5 There may be slight current fluctuations above and below the configured current limit setting. This can be due to the current control within the factory preset deadband. Confirmation of this control process may be witnessed in the Fast Charge test.
- 6 There may be a delay of up to 2 minutes before the currents stabilize between rectifiers.
- 7 There may be a delay of up to 10 seconds before the LVD changes state.
APS systems may not display a Manual Connect alarm on the SC200 or SC100 if the system voltage is above the LVD disconnect voltage.
Perform the test on each LVD control module within the system.
For manual LVD operation see details in the System Controller Operation Handbook.
For an explanation of LVD LED indications see Troubleshooting on page [52](#).

System Alarms

Equipment Required:

- dc load bank
- dc power supply

Test	Test procedure	Adjustment
General notes about alarm testing	<ul style="list-style-type: none"> • For all alarms check the following where applicable: <ul style="list-style-type: none"> • SC200 or SC100 LED status. • SC200 or SC100 display indication. • DCTools alarm indication • Remote alarm indication (PowerManagerII, SNMP traps, and so on) • Digital outputs (relays). • Reducing the alarm recognition time will reduce the alarm testing time. • There may be more than 1 method to perform the following alarm tests. 	
Low Float Note 1	<ul style="list-style-type: none"> • Increase the <i>Low Float Threshold</i> to just below the float voltage. • Reduce the system voltage by heating the battery temperature sensor - or - • Disconnect the battery from the system. • Start a <i>Battery Test</i>. • The system voltage will fall. • Ensure alarm operates. 	
Low Load	<ul style="list-style-type: none"> • Test as for the <i>Low Float</i> test. Note that the <i>Low Load Threshold</i> is lower than the <i>Low Float threshold</i>. • Ensure alarm operates. 	
High Float Note 1	<ul style="list-style-type: none"> • Set the system <i>Float Voltage</i> above the <i>High Float Threshold</i>. - or - • Reduce the <i>High Float Threshold</i> and increase the system voltage by starting an <i>Equalize</i>. - or - • Reduce the <i>High Float Threshold</i> and increase the system voltage by cooling the battery temperature sensor. • Ensure alarm operates. 	
High Load	<ul style="list-style-type: none"> • Increase the system voltage. • Test as for the High Float test. □ Note the <i>High Load Threshold</i> is higher than the <i>High Float Threshold</i> • Ensure alarm operates. 	
Rectifier Fail	<ul style="list-style-type: none"> • Turn off a rectifier ac MCB (if fitted). • The rectifier will turn off. • Ensure alarm operates. 	
Multiple rectifier fail	<ul style="list-style-type: none"> • Turn off the ac MCBs to 2 rectifiers (if fitted). • The rectifiers will turn off. • Ensure alarm operates. 	
Rectifier comms lost	<ul style="list-style-type: none"> • Remove a rectifier from the system. • Ensure alarm operates. 	

Test	Test procedure	Adjustment
Multiple Rectifier comms lost	<ul style="list-style-type: none"> Remove 2 rectifiers from the system. Ensure alarm operates. 	
Partial AC Fail	<ul style="list-style-type: none"> Turn off the ac to more than 20% of the rectifiers in the system. Ensure alarm operates. 	
AC Fail	<ul style="list-style-type: none"> Turn off all ac to the system. Ensure alarm operates. 	
System Overload	<ul style="list-style-type: none"> Reduce the <i>System Overload Recognition Period</i> to 0 minutes. Apply load to the system. Turn off rectifiers until the <i>System Overload Threshold</i> is exceeded. Ensure alarm operates. 	
Load Fuse Fail Note 2	<ul style="list-style-type: none"> Apply load to the system. Turn off the MCB feeding the load bank. Ensure alarm operates. 	
Battery Fuse Fail	<ul style="list-style-type: none"> Turn off a Battery MCB or remove a Battery Fuse. Ensure alarm operates. 	
Battery Test Fail	<ul style="list-style-type: none"> See Battery Test in the System Controller Operation Handbook for details. 	
MOV Fail	<ul style="list-style-type: none"> Remove a MOV cartridge from the MOV housing (if fitted). Ensure alarm operates. 	
ACD Fan Fail	<ul style="list-style-type: none"> Stop the ACD Fan (if fitted). Ensure alarm operates. 	
LVD alarms	<ul style="list-style-type: none"> See LVD test on page 92 for details. 	
Battery Temperature Low	<ul style="list-style-type: none"> Increase the <i>Battery Temperature Low Threshold</i> above the current temperature. - or - Cool the temperature sensor until the threshold is exceeded. Ensure alarm operates. 	
Battery Temperature High	<ul style="list-style-type: none"> Reduce the <i>Battery Temperature High Threshold</i> below the current temperature. - or - Heat the battery temperature sensor until the threshold is exceeded. Ensure alarm operates. 	
Sensor Fail	<ul style="list-style-type: none"> Disconnect the battery temperature sensor from the I/O board (XH7). Ensure alarm operates. Replace the battery temperature sensor. Disconnect the current sensor (XH6). Ensure alarm operates. Replace the current sensor. Disconnect the voltage sensor (XH9). Ensure alarm operates. Replace the voltage sensor. 	
Equalize	<ul style="list-style-type: none"> For details see Equalize test in System Controls on page 92. 	

Test	Test procedure	Adjustment
Fast Charge	<ul style="list-style-type: none"> For details see Fast Charge test in System Controls on page 92. 	
Battery Test	<ul style="list-style-type: none"> For details see Battery Test in System Controls on page 92. 	
In Discharge Note 3	<ul style="list-style-type: none"> Connect load to the system. Turn off the ac supply to the rectifiers. Allow the battery to start discharging. Ensure alarm operates. 	
Config Error Note 4	<ul style="list-style-type: none"> Load incorrect configuration file. - or - Remove all rectifiers from the system. Apply an incorrect external voltage to the system: <ul style="list-style-type: none"> 24V for a 48V system 48V for a 24V system Ensure alarm operates. 	
User Assigned Alarms	<ul style="list-style-type: none"> See User Digital Input test on page 98. 	
Battery Current Limit	<ul style="list-style-type: none"> For details see Battery Current Limit test in System Controls on page 92. 	
Rectifier No Load	<ul style="list-style-type: none"> Ensure the dc load and batteries are isolated from the system. Ensure alarm operates. 	
Rectifier Current Limit	<ul style="list-style-type: none"> Apply a dc load to the system. Turn off rectifiers until the remaining rectifiers reach the <i>Rectifier Current Limit</i> threshold. - or - Set the <i>Rectifier Current Limit</i> slightly below the existing rectifier current being delivered to the load. Ensure alarm operates. 	
High Rectifier Temperature Note 5	<ul style="list-style-type: none"> Unable to test. 	
AC Phase 1/2/3 Fail Note 6	<ul style="list-style-type: none"> Turn off ac phase 1 to the power system. Ensure alarm operates. Repeat for phase 2 and phase 3. 	
AC Phase 1/2/3 Voltage Note 6	<ul style="list-style-type: none"> Reduce the <i>High AC Threshold</i> below the existing ac voltage. Ensure alarm operates. Increase the <i>Low AC Threshold</i> above the existing ac voltage. Ensure alarm operates. 	
AC Frequency Note 6	<ul style="list-style-type: none"> Change the Nominal AC Frequency setting. Change the AC Frequency Threshold. Ensure alarm operates. 	
Engine Run Option Note 7	<ul style="list-style-type: none"> Change the state of the digital input with <i>Engine Run</i> function. Ensure alarm operates. 	

Notes

- 1 Ensure Alarm Tracking is disabled. Ensure Temperature Compensation is enabled.
- 2 If the load is not connected to the load MCBs and if an electronic Fuse Fail detect circuits is installed, this test can also be performed as follows:
 - Turn off the load MCB
 - Connect a high impedance path ($>100\text{k}\Omega$) between the end load side of the MCB and the Common Bus. (The impedance path can also be created by touching these points with your hand.)
- 3 Ensure the battery discharge is high enough. Allow for the recognition time.
- 4 This alarm will be displayed if the incorrect configuration or incorrect rectifiers are used in the system. It is not recommended that this be tested as it is very unlikely for an incorrect configuration to be installed after commissioning.
- 5 This alarm is originated from the rectifier. It can only be tested by increasing the internal temperature of the rectifier.
- 6 These alarms are only available with the external ac metering option.
- 7 A digital input must be configured for this test to function. See details in the System Controller Operation Handbook.

Digital Inputs

Test	Test procedure	Adjustment
Digital Input 1	<ul style="list-style-type: none">• Change the state of the Digital input.• Ensure any alarms mapped to the digital output (relay) activate.• Ensure the Digital Input Alarm Name is correct.	
Digital Input 2	As for Digital Input 1.	
Digital Input 3	As for Digital Input 1.	
Digital Input 4	As for Digital Input 1.	
Digital Input 5	As for Digital Input 1.	
Digital Input 6	As for Digital Input 1.	
User Assigned Digital Inputs Note 1	<ul style="list-style-type: none">• As for Digital Input 1.• Check the severity and digital output (relay) mapping is correct.	

Notes

- 1 As the Digital Inputs can be configured for many different digital input devices, specific tests have not been detailed on this test sheet.

Digital Outputs (Relays)

Test	Test procedure	Adjustment
Digital Output 1 Note 1	<ul style="list-style-type: none"> Refer to <i>Digital Outputs</i> in the SC200 or SC100 handbook. Follow the instructions to manually change the state of the digital output. When the digital output is <i>Active</i>, check any remote alarms are extended. When the digital output is <i>Inactive</i>, check any remote alarms are return to their original state. 	
Digital Output 2	As for Digital Output 1.	
Digital Output 3	As for Digital Output 1.	
Digital Output 4	As for Digital Output 1.	
Digital Output 5	As for Digital Output 1.	
Digital Output 6 Note 2	As for Digital Output 1.	
User assigned Digital Outputs	As for Digital Output 1.	

Notes

- 1 Digital Outputs can also be checked as other system tests are performed.
- 2 Digital Output 6 is also used as the Monitor Fail alarm relay. It will de-energize if the I/O board loses power or loses communication with the SC200 or SC100. Test extended alarms by removing the power to the I/O board. This will de-energize the relay.

Commissioning Completed

Restore the original (backed-up prior to the testing) configuration file.

Use DCTools to change any configuration file settings that were noted as incorrect during the Commissioning tests.

EQUIPMENT INCIDENT REPORT

Please enter as much information as you can. Send the completed form, together with the item for repair to your nearest authorized service agent. NOTE: Only one fault to be recorded per form.

For further information contact your local Eaton dc product supplier or Eaton (see contact details on page [103](#)). Or email: CustomerServiceNZ@eaton.com

Date: _____

Customer Information

Company: _____

Postal Address: _____

Return Address: _____
(Not PO Box)

Telephone: _____ Fax: _____ Email: _____

Contact Name: _____

Location of Failure

Product code: _____ Serial number: _____ Document number: _____

System type installed in: _____ Serial number: _____

Site name or location: _____

Fault discovered	<input type="checkbox"/> Delivery	<input type="checkbox"/> Unpacking	<input type="checkbox"/> Installation
	<input type="checkbox"/> Initial test	<input type="checkbox"/> Operation after _____ years	<input type="checkbox"/> Other _____
Failure source	<input type="checkbox"/> Design	<input type="checkbox"/> Manufacturing	<input type="checkbox"/> Documentation
	<input type="checkbox"/> Transportation	<input type="checkbox"/> Installation	<input type="checkbox"/> Handling

Effect on system operation	<input type="checkbox"/> None	<input type="checkbox"/> Minor	<input type="checkbox"/> Major	_____
-----------------------------------	-------------------------------	--------------------------------	--------------------------------	-------

INFORMATION (fault details, circumstances, consequences, actions)

Internal use only.


Reference No: _____ RMA: _____ NCR: _____ Signature: _____ Date: _____

INFORMATION continued (fault details, circumstances, consequences, actions)

SG/03 ISS06

For product information and a complete listing of worldwide sales offices, visit Eaton's website at: dcpower.eaton.com or email: DCinfo@eaton.com

For technical support contact either your local Eaton dc product representative, the closest office from the following list, telephone **(+64) 3-343-7448**, or email CustomerServiceNZ@eaton.com



Australia:	1300-877-359
Canada:	1-800-461-9166
Central America:	+52 55-9000-5252
China:	+86 755-2757-2666 - extension 3024
Europe / Middle East / Africa:	+44 1243-810-500
Hong Kong / Korea / Japan:	+852 2745-6682
India:	+91 11-4223-2325
New Zealand	0508 NZ Service (0508-697-378)
Singapore / South East Asia:	+65 6825-1668
South America:	+54 11-4124-4000
South Pacific:	+64 3-343-7448
Taiwan:	+886 2-6600-6688 or free call 0800-038-168
United States of America (Toll Free):	1-800-843-9433 - option 2 - option 6

?

??? on SC200 or SC100 Display • 47

A

AC Earth

AC-DC Earth Connection • 22

Site Earth • 17

AC Supply

AC Discrimination • 17

AC Isolator • 2

AC MCB • 2

Connection to AC Supply • 33, 39

Earth Leakage Current • 17, 69

High AC Voltage Protection • 17

Specifications • 69

Startup • 39

Transient Voltage Protection • 17, 85

Tripping Curve • See AC Discrimination

Accessories • See Spares

Alarms

Audible Alarm Indication • 47

LEDs (SC200 or SC100) • 47

LVD Status LED • 6, 55

Monitor OK Alarm • 6

Rectifier Alarms • 3, 39

Rectifier LEDs • 3

Relays • See Digital Outputs (Relays)

SC200 or SC100 Alarms • 39, 47

Sound • See Audible Alarm Indication

APR-3G Series Rectifiers • See Rectifiers

Audible Alarm Indication • 47

B

Battery

Battery Charging • 41

Battery Fuses • 2, 25, 32, 54, 58

Disposal and Recycling • 64

Location • 2

Mid-Point Monitoring (MPM) • 9, 27, 74

Reverse Polarity • 41

Shelves • 27

String Fail Alarm • 9, 55, 63

Temperature Sensor • 6, 7, 30, 73

Time Remaining • 9

Battery Circuit Breakers • 54

Connecting to MCBs • 25

Location • 2

Browsers (recommended) • 5

Bus Voltage

Bus Voltage Sense • 6

C

Characterization of LVD • 61

Circuit Breakers

Battery Circuit Breakers • 54

Connecting to MCBs • 25

Load Circuit Breakers • 24, 54

Location • 2

Replacing or Adding a Load MCB • 57

Clearances • 20

Commissioning • 89

Communications • 4, 74

Browsers (recommended) • 5

Communications Options • 8

Connector • 4, 7

DCTools • 5, 8, 48, 65

Ethernet Communications • 8

GSM Modem Communications • 8

PSTN Modem Communications • 8

SNMP • 8

USB Communications • 48

Web Server • 8

Configuration File • 40, 44, 59

Backup and Restore • 44

Connection to AC Supply • 33, 39

Current

Rectifier Current • 45

Current Sense • 6, 7, 8, 31, 73

External Current Sensor • 31, 83

D

Damage (transport) • 14, 38

DC Common

AC-DC Earth Connection • 22

DCTools • 5, 8, 48, 65
Software Versions • 5
Digital Inputs • 73
Connectors • 6, 7, 80
Digital Outputs (Relays) • 8, 73
Connectors • 6, 7, 80
Discrimination • See AC Discrimination

E

Earth
AC-DC Earth Connection • 22
Earth Leakage Current • 17, 69
Site Earth • 17
Ethernet
Connector • 4, 7
Ethernet Communications • 8
Problems • See Troubleshooting
External Current Sensor • 31, 83

F

Floor
Floor Fixing • 20
Plinth (for raised floors) • 2
Fuse
Battery Fuses • 2, 25, 32, 54, 58
Load Fuses • 24, 54, 58, 59
Rectifier Fuses • See AC Discrimination

G

GSM Modem Communications • 8

H

High AC Voltage Protection • 17

I

Identity Information • 50
Input/Output (I/O) Board
Additional I/O • See SiteSure-3G I/O module
Connections to other system components • 7
Connector Pin-outs • 80
Description • 6
Digital Inputs • 73
I/O Board Mapping • 59, 61
Input/Output Cabling • 31
Location • 2

LVD Status LED • 6, 55
Power On LED • 6, 55, 61
Repair and Return • 101
Replacing the Input/Output Board • 61

K

Keypad
Keypad Access Security • 46

L

LCD • 46
LEDs
LEDs (SC200 or SC100) • 47
LVD Status LED • 6, 55
Power On LED • 6, 55, 61
Rectifier LEDs • 3
Troubleshooting • 52
Lightning Protection • See Transient Voltage Protection
Load Circuit Breakers • 24, 54
Connecting to MCBs • 25
Location • 2
Replacing or Adding a Load MCB • 57
Load Fuses • 24, 54, 58, 59
Low Voltage Disconnect (LVD) • 8
Characterization of LVD • 61
Connectors • 6, 7, 80
LVD Alarms • See Troubleshooting
LVD Status LED • 6, 55
Problems • 55
LVD • See Low Voltage Disconnect (LVD)

M

Main Screen • 45
Mid-Point Monitoring (MPM) • 9, 27, 74
String Fail Alarm • 9, 55, 63
Modem (PSTN, GSM) • See Communications
Monitor OK Alarm • 6
MOVs • See Transient Voltage Protection
Monitoring and replacing MOVs • 63
MOV Fail Alarm • 85
MPM • See Mid-Point Monitoring (MPM)

N

Network Management System (NMS) • See SNMP

O

Options • 8, See Spares
Output Voltage and Current • 69

P

PC/Laptop (Connection via USB) • See USB Communications
Plinth (for raised floors) • 2
Polarity
 Reverse Polarity • 41
Power
 System Power • 69
PowerManagerII • 5
Protection
 Transient Voltage Protection • 17, 85
PSTN Modem Communications • 8

R

Raised Floor Plinth • See Plinth (for raised floors)
Rectifiers • 72
 Description • 3
 Earth Leakage Current • 17, 69
 Inserting the Rectifiers • 38
 Location • 2
 Output Voltage and Current • 69
 Problems • See Troubleshooting
 Rectifier Alarms • 3, 39
 Rectifier blank panel • 56
 Rectifier Current • 45
 Rectifier Fuses • See AC Discrimination
 Rectifier LEDs • 3
 Rectifier Replacement • 56
 Registration • 39
 Repair and Return • 101
 Startup • 39
 System Power • 69
Relays • See Digital Outputs (Relays)
 Monitor OK Alarm • 6
Repair and Return • 101
Residual Current Devices (RCD) • 17

Reverse Polarity • 41

RS232 • 48

 Connector • 4, 7

Modem (PSTN, GSM) • See Communications

Null-modem RS232 Cable • 65, 66

S

Safety Equipment • See Tools

SC200 or SC100

??? on SC200 or SC100 Display • 47

Configuration File • 40, 44, 59

Connections to other system components • 7

Connector Pin-outs • 79, 80

Description • 4

Identity Information • 50

Keypad • 46

LEDs (SC200 or SC100) • 47

Location • 2

Main Screen • 45

Problems • See Troubleshooting

Repair and Return • 101

Replacing the System Controller • 59

SC200 or SC100 Alarms • 39, 47

Security • See Keypad Access Security

Startup • 45

Security

 Keypad Access Security • 46

Security Door • 2

Servicing • 14, 101, 103

SiteSure-3G I/O module • 32

 Connection to DV2-3G • 32

SMS Text Messaging • See GSM Modem Communications

SNMP • 8

Software Versions • 5

Sound • See Audible Alarm Indication

Spares • 66

Specifications • 69

String Fail Alarm • 9, 55, 63

System Power • 69

T

Technical Assistance • 103

Temperature

 Temperature Sensor • 6, 7, 30, 73

Text Messaging (SMS) • See GSM Modem Communications

Time Remaining • 9

Tools • 65

Torque Settings • 67

Transient Voltage Protection • 17, 85

 Monitoring and replacing MOVs • 63

 MOV Fail Alarm • 85

Troubleshooting • 52

 Damage (transport) • 14, 38

 Repair and Return • 101

 Servicing • 14, 101, 103

 Technical Assistance • 103

U

USB

 Connector • 4, 7

 USB Cable • 48, 66

 USB Communications • 48

V

Voltage (Bus) • See Bus Voltage Sense

Voltage Control

 Bus Voltage Sense • 6

Voltage Feed Module • 7

W

Web

 Browsers (recommended) • 5

 Web Server • 8